
# Series RS2H


ø50, ø63, ø80




## Construction

Double acting (DL, DM)







(TL, TM)

\* The numbers are the same as the "Construction" of the RS2H series catalog (CAT.ES20-216).

#### Seal Kit List

|     | 204: · · · · · · |          |      |  |  |  |
|-----|------------------|----------|------|--|--|--|
| No. | Description      | Material | Note |  |  |  |
| 37) | Piston seal      | NBR      |      |  |  |  |
| 38  | Rod seal         |          |      |  |  |  |
| 39  | Tube gasket      |          |      |  |  |  |
| 40  | O-ring           |          |      |  |  |  |

38 is a non-replaceable part, so it is not included in the seal kit.

### Replacement Parts: Seal Kit

| D                 | Kit no.       |                           |               |                  |
|-------------------|---------------|---------------------------|---------------|------------------|
| Bore size<br>(mm) | Double acting | Double acting spring type | Single acting | Contents         |
| 50                | RS2H50D-PS    | RS2H50T-PS                |               | Set of left nos. |
| 63                | RS2H63D-PS    | RS2H63T-PS                |               | 37. 39. 40       |
| 80                | RS2H80D-PS    | RS2H80T-PS                |               | ₩, ₩, ₩          |

- \* Seal kit includes  $\mathfrak{D}$ ,  $\mathfrak{B}$ ,  $\mathfrak{A}$  for ø50 to ø80. Order the seal kit based on each bore size.
  - Since the seal kit does not include a grease pack, order it separately.
    Grease pack part no.: GR-S-010 (10 g)

## Replacement Parts: Shock Absorber

| Bore size (mm) | Order no. |  |  |  |
|----------------|-----------|--|--|--|
| 50             | RS2H-R50  |  |  |  |
| 63             | RS2H-R63  |  |  |  |
| 80             | RS2H-R80  |  |  |  |