



Direct Operated 3 Port Solenoid Valve

For Air, Water, Oil, Steam





Solenoid valves for various fluids used in a wide variety of


Improved corrosion resistance

Special magnetic material adopted

Englosure: Equivalent to IP65

Low-noise (construction

Special construction enables to reduce the metal noise. (DC specification)



Reduced power consumption

(DC specification)

 $VX31: 6 \text{ W} \rightarrow \textbf{4.5} \text{ W}$

VX32: $8 \text{ W} \rightarrow 7 \text{ W}$ VX33: $11.5 \text{ W} \rightarrow 10.5 \text{ W}$

Flame resistance

UL94V-0 conformed
Flame resistant mold coil material

Improved maintenance performance

Maintenance is performed easily due to the threaded assembly.

Direct Operated 3 Port Solenoid Valve

For Air, Water, Oil, Steam

New Series VX31/32/33





Normally Closed (N.C.) / Normally Open (N.O.) / Common (COM.)

Orifice diameter			Material							
Model	Office diameter		Port size	D. d.	Guide	Seal		Fluid		
	ø1.5mm	ø2.2mm	ø3mm	ø4mm		Body	pin N	Main valve poppet	Fixed sealant	
VX31	•	•	•	_	1/8, 1/4	C37	PPS	NBR	NBR	A: 14/ 1
VX32	_	•	•	•	1/4, 3/8	Stainless	Stainless	FKM EPDM	FKM EPDM	Air, Water, Oil, Steam
VX33		•	•	•	1/4, 3/8	steel	steel	FFKM	PTFE	Oii, Gleaiii

Manifold: Normally Closed (N.C.) / Normally Open (N.O.) / Common (COM.)

Model		Orifice of	diameter		Port size (Common SUP/EXH type)			Material			Florid
Model	ø1.5mm	ø2.2mm	ø3mm	ø4mm	IN port	OUT port	EXH port	Body	Guide pin	Seal	Fluid
VVX31	•	•	•	_					PPS	NBR	
VVX32	_	•	•	•	1/4	1/8, 1/4	1/4	C37	Stainless	FKM	Air, Oil
VVX33	_	•	•	•					steel	EPDM	

applications—New WX Serfles variations

Direct Operated 2 Port

New VX21/22/23

For Air, Vacuum, Water, Steam, Oil



Valve type	Port size	Orifice dia. mmø	
N.C./N.O.	1/8 to 1/2	2 to 10	

Pilot Operated 2 Port

VXP21/22/23

For Steam (Air, Water, Oil)



Valve type	Port size	Orifice dia. mmø
N.C./N.O.	1/4 to 2 32A to 50A	10 to 50

2 Port for Dust Collector (Solenoid type, Air Operated type)

VXF21/22, VXFA21/22

For Air

N.C.



3/4 to 11/2

20 to 40

Pilot Operated 2 Port

New VXD21/22/23

For Air, Water, Oil



Valve type	Port size	Orifice dia. mmø
N.C./N.O.	1/4 to 1 32A to 50A	10 to 50

Water Hammer Relief, **Pilot Operated 2 Port**

VXR21/22/23

For Water, Oil



Valve type	Port size	Orifice dia. mmø
N.C./N.O.	1/2 to 2	20 to 50

Air Operated 2/3 Port

VXA21/22, VXA31/32

For Air, Vacuum, Water, Oil



Valve Port Orifice dia. Model type size mmø VXA21/22 N.C./N.O. 1/8 to 1/2 3 to 10 VXA31/32 COM. 1/8 to 3/8 1.5 to 4 Pilot Operated 2 Port for Zero Differential Pressure

New VXZ22/23

For Air, Vacuum, Water, Oil



Valve type	Port size	Orifice dia. mmø
N.C./N.O.	1/4 to 1	10 to 25

Pilot Operated 2 Port for High Pressure

VXH22



Valve type	Port size	Orifice dia. mmø
N.C.	1/4 to 1/2	10

The VX series has been renewed as the new VX series. with a new construction.

specifications

For Air

For Water

For Oil

For Steam

Direct Operated 3 Port Solenoid Valve

Series VX31/32/33

For Air, Water, Oil, Steam



Single Unit

Valve

Normally closed (N.C.) Normally open (N.O.) Common (COM.)

■ Solenoid Coil

Coil: Class B, Class H

■ Rated Voltage

100 VAC, 200 VAC, 110 VAC, 220 VAC, 240 VAC, 230 VAC, 48 VAC, 24 VDC, 12 VDC

■ Material

Body — C37, Stainless steel Seal — NBR, FKM, EPDM, PTFE, FFKM

■ Electrical Entry

- Grommet
- Conduit
- DIN terminal
- Conduit terminal



Normally Closed (N.C.) / Normally Open (N.O.) / Common (COM.)

	Model	VX31	VX32	VX33
dia.	1.5 mmø		_	_
	2.2 mmø	•	•	•
Orifice	3 mmø	•		•
ŏ	4 mmø	_		•
Port size		1/8	1/4	1/4
	OIT SIZE	1/4	3/8	3/8



Manifold

■ Valve

Normally closed (N.C.) Normally open (N.O.) Common (COM.)

■ Base

Common SUP/EXH type

■ Solenoid Coil

Coil: Class B, Class H

■ Rated Voltage

100 VAC, 200 VAC, 110 VAC, 220 VAC, 240 VAC, 230 VAC, 48 VAC, 24 VDC, 12 VDC

■ Material

Body — C37 Base — Aluminum Seal — NBR, FKM, EPDM

■ Electrical Entry

- Grommet
- Conduit
- DIN terminal
- Conduit terminal



Normally Closed (N.C.) / Normally Open (N.O.) / Common (COM.)

	Model		VX31	VX32	VX33	
ä.	1.5	mmø			_	
o G	2.2	mmø			•	
Orifice dia.	3	mmø	•	•	•	
ŏ	4	mmø	_	•	•	
(90,4)	- type)	IN port		1/4		
SIID/EXI	Port size	EXH port OUT port IN port	1/8, 1/4			
(Commor		EXH port		1/4		

Common Specifications

Standard Specifications

	Valve cons	truction	Direct operated poppet
Valve	Withstand pressure (MPa)		3.0
	Body mate	rial	C37, Stainless steel
specifications	Seal materi	al	NBR, FKM, EPDM, PTFE, FFKM
	Enclosure		Dusttight, Low jetproof (equivalent to IP65)*
	Environme	nt	Location without corrosive or explosive gases
	Rated voltage	AC (Class B coil, Built-in full-wave rectifier type) AC (Class H coil)	100 VAC, 200 VAC, 110 VAC, 220 VAC, 230 VAC, 240 VAC, 48 VAC
		DC	24 VDC, 12 VDC
Coil	Allowable v	oltage fluctuation	±10% of rated voltage
specifications	Allowable	AC (Class B coil, Built-in full-wave rectifier type)	5% or less of rated voltage
	leakage voltage	AC (Class H coil)	20% or less of rated voltage
	vollage	DC	2% or less of rated voltage
	Coil insulat	tion type	Class B, Class H

^{*} Electrical entry, Grommet with surge voltage suppressor (GS) has a rating of IP40.

Solenoid Coil Specifications

DC Specification

Model	Power consumption (W)	Temperature rise (C) Note)
VX31	4.5	45
VX32	7	45
VX33	10.5	60

Note) The values are for an ambient temperature of 20 $^{\circ}\text{C}$ and at the rated voltage.

AC Specification (Class B coil, Built-in full-wave rectifier type)

Model	Apparent power (VA)*	Temperature rise (C) Note)		
VX31	7	55		
VX32	9.5	60		
VX33	12	65		

^{*} There is no difference in the frequency and the inrush and energized apparent power, since a rectifying circuit is used in the AC (Class B). Note) The values are for an ambient temperature of 20°C and at the rated voltage.

AC Specification (Class H coil)

to openium (control of the control o							
Model		Apparent p	Temperature rise (C) Note)				
Model	Frequency (Hz)	Inrush	Temperature rise (C)				
VX31	50	33	14	65			
VASI	60	28	12	60			
VX32	50	65	33	100			
V A 3 Z	60	55	27	95			
VX33 50		94	50	120			
V A 3 3	60	79	41	115			

Note) The values are for an ambient temperature of 20 $\!^{\circ}\text{C}$ and at the rated voltage.




For Water

For Oil

For Steam

Applicable Fluid Check List


All Options (Single Unit)



Fluid and application	Option	Seal m	aterial	Body material/	Guide pin	Coil insulation	Note	
Fluid and application	symbol	Main valve poppet	Fixed sealant	Shading coil material Note 6)	material	type Note 4)	Note	
Air	Nil	NBR	NBR	C37	PPS	В		
All	G	INDI	INDIN	Stainless steel	113	В		
Medium vacuum, Non-leak,	M Note 1, 2)	FKM	FKM	Stainless steel	PPS	В		
Oil-free	V Note 1, 2)	FKIVI	FRIVI	C37	FF3	ь		
Water	Nil	NBR	NBR	C37	PPS	В		
vvalei	G	INDI	INDI	Stainless steel	113	В		
Heated water	E	EPDM EPDM C37/Cu Sta		Stainless steel	Н	_		
nealed water	Р	EPDINI	EPDIVI	Stainless steel/Ag	Stairliess steel	П		
	Α	FKM	FKM -	C37	PPS	В		
Oil Note 3)	Н			Stainless steel	113			
OII Note of	D	LVINI		C37/Cu	Stainless steel			
	N			Stainless steel/Ag	Stairliess steel	П		
Steam (May 1939C)	S	FFKM	PTFE	C37/Cu	Stainless steel	Н	COM only	
Steam (Max.183°C)	Q	FFKIVI	PIFE	Stainless steel/Ag	Stairliess steel	"	COM. only	
Copper-free, Fluoro-free Note 5)	J	EPDM	EPDM	Stainless steel	PPS	В		
Copper-free, Fluoro-free 1000 37	P EPDIN EPDIN Stainless steel/Ag		Stainless steel/Ag	Stainless steel	Н	_		
	В	EPDM	EPDM	C37	PPS			
Others	С	FFKM	PTFE	U3/	Stainless steel	В	COM. only	
	K Note 1, 2)	FFKIVI	PIFE	Stainless steel	Stallilless steel		COM. only, Oil-free	

^{*} If using for other fluids, please consult with SMC.

All Options (Manifold)*



Fluid and application	Option	Seal m	naterial	Body material/	Guide pin	Coil insulation
Fluid and application	symbol	Main valve poppet	Fixed sealant	Shading coil material Note 6)	material	type Note 4)
Air	Nil	NBR NBR		C37	PPS	В
Medium vacuum, Non-leak, Oil-free	V Note 1, 2)	FKM	FKM	C37	PPS	В
Oil Note 3)	Α	FICA	FIZM	C37	PPS	В
Oll Note 3)	D	FKM	FKM	C37/Cu	Stainless steel	Н
Otherwa	В	EDDM	EPDM	C37	PPS	В
Others	E	EPDM	EPDM	C37/Cu	Stainless steel	Н

^{*} Aluminum is only available with the material for a manifold base.

Note 1) The leakage amount (10⁻⁶ Pa·m³/s) of "V", "M" options are values when differential pressure is 0.1 MPa.

Note 2) "V", "M" and "K" options are for oil-free treatment.

Note 3) The dynamic viscosity of the fluid must not exceed 50 mm²/s or less.

Note 4) Coil insulation type Class H: AC spec. only, Class B/AC spec.: built-in full-wave rectifier type only

Note 5) The nuts (non-welded parts) are nickel plated on the C37 material.

Note 6) There is no shading coil attached to DC spec. or Class B/AC spec.

^{*} If using for other fluids, please consult with SMC.

Series VX31/32/33

For Air /Single Unit

(Inert gas, Non-leak, Medium vacuum)


Model / Valve Specifications

N.C.

N.O.

COM.

Passage symbol



Passage symbol

Passage symbol



Port size			Max. opera	Max. operating pressure differential (MPa)		Flow characteristics			Max. system pressure	Weight
(mmø)		N.C.	N.O.	COM.	C[dm ³ /(s·bar)]	b	Cv	(MPa)	(g)	
1/8	1.5	VX311□-01	1	1	0.7	0.29	0.32	0.08		
(6A)	2.2	VX312□-01	0.7	0.5	0.4	0.60	0.25	0.15		
(OA)	3	VX313□-01	0.3	0.3	0.2	0.82	0.20	0.20		380
	1.5	VX311□-02	1	1	0.7	0.29	0.32	0.08		
		VX312□-02	0.7	0.5	0.4	0.60	0.25	0.15		
	2.2	VX322□-02	1.2	1	0.7	0.64	0.40	0 0.17		530
1/4	1/4	VX332□-02	1.6	1.6	1	0.64	0.40	0.17		730
(8A)		VX313□-02	0.3	0.3	0.2	0.82	0.20	0.20		380
	3	VX323□-02	0.6	0.5	0.3	1.1	0.25	05 0.07	2.0	530
		VX333□-02	1	0.9	0.6	1.1	0.25	0.27		730
	4	VX324□-02	0.3	0.25	0.2	1.0	0.20	0.38		530
	4	VX334□-02	0.5	0.4	0.3	1.6	0.20	0.36		730
	0.0	VX322□-03	1.2	1	0.7	0.64	0.40	0.17		530
	2.2	VX332□-03	1.6	1.6	1	0.64	0.40	0.17		730
3/8	0	VX323□-03	0.6	0.5	0.3	1.1	0.25	0.27		530
(10A)	3	VX333□-03	1	0.9	0.6	1.1	0.20	0.27		730
	4	VX324□-03	0.3	0.25	0.2	1.6	0.20	0.39		530
	4	VX334□-03	0.5	0.4	0.3	1.0	0.20	0.38		730

Note) Weight of grommet type. Add 10 g for conduit, 30 g for DIN terminal, and 60 g for conduit terminal type respectively.

Also, add 60 g for VX31□□, 80 g for VX32□□ and VX33□□ respectively for bracket option.

Fluid and Ambient Temperature

_	Fluid tempe		Ambient
Power source	Solenoid valve	option (symbol)	temperature
	Nil, G	(°C)	
AC	-10 Note) to 60	-10 Note) to 40	-20 to 60
DC	-10 Note) to 60	-20 to 40	

Note) Dew point temperature: -10°C or less

Valve Leakage

Internal Leakage / External Leakage


	Max. operating	Leakage rate			
Seal material	pressure differential	Air	Non-leak, Medium vacuum Note)		
NDD EKM	From 0 to less than 1 MPa	1 cm³/min or less	10 ⁻⁶ Pa⋅m³/sec		
NBR, FKM	1 MPa or more	2 cm³/min or less	or less		

Note) The leakage amount (10-6 Pa-m³/sec) for the "V" and "M" option are values when the differential pressure is 0.1 MPa.



[•] Refer to "Glossary" on page 31, for details on the max. operating pressure differential and the max. system pressure.

How to Order (Single Unit)



(S, L, Z) and rated voltage.

* Surge voltage suppressor is integrated into the AC/Class B coil, as a standard.

Table (1) Model - Orifice Diameter - Port Size

	Solenoid v	alve mode		Orifice symbol (diameter)			
Model	VX31	VX32	VX33	1 (1.5 mmø)	2 (2.2 mmø)	3 (3 mmø)	4 (4 mmø)
-	01 (1/8)	_	_	•	•	•	_
Port symbol	02 (1/4)	_	_	•	•	•	_
(Port size)	_	02 (1/4)	02 (1/4)	_	•	•	•
(. 3 6/20)	_	03 (3/8)	03 (3/8)	_	•	•	•

Table (2) Solenoid Valve Option

Option symbol	Seal ma Main valve poppet		Body material/ Shading coil material Guide pin material		Coil insulation type	Note Note)	
Nil			C37				
G	NBR	NBR	Stainless steel			_	
М	FKM	Stainless		PPS	В	Non-leak (10 ⁻⁶ Pa⋅m³/sec),	
V	FIXIVI	FKM	C37			Medium vacuum (0.1 Pa.abs), Oil-free	

Note) The leakage amount (10^{-6} Pa·m³/sec) for the "V" and "M" option are values when the differential pressure is 0.1 MPa.

Table (3) Rated Voltage - Electrical Option

	` '				•
	Dated valt	000		Class E	3
	Rated voltage		S	L	Z
AC DC	0	Voltage	With surge voltage suppressor	With light	With light and surge voltage suppressor
	1	100 V		•	
	2	200 V		•	
	3	110 V		•	
AC	4	220 V	Note)	•	Note)
	7	240 V		_	
	8	48 V			
	J	230 V		_	
DC	, 5	24 V	•	•	•
	´ 6	12 V	•	_	_

Note 1) Option S, Z are not available as surge voltage suppressor is integrated into the AC/Class B coil, as a standard.

* Class H coil is not available.

Series VVX31/32/33

For Air /Manifold

(Inert gas, Non-leak, Medium vacuum)

Solenoid Valve for Manifold / Valve Specifications


N.C.

N.O.


COM.




Passage symbol







Passage symbol



Orifice diameter (mmø) Model	Max. operating pressure differential (MPa)			Flow characteristics			Max. system pressure	
(1111110)		N.C.	N.O.	COM.	C[dm ³ /(s·bar)]	b	Cv	(MPa)
1.5	VX311□-00	1	1	0.7	0.29	0.32	80.0	
	VX312□-00	0.7	0.5	0.4	0.60	0.25	0.15	
2.2	VX322□-00	1.2	1	0.7	0.64	0.40	0.17	
	VX332□-00	1.6	1.6	1	0.04	0.40	0.17	
	VX313□-00	0.3	0.3	0.2	0.82	0.20	0.20	2.0
3	VX323□-00	0.6	0.5	0.3	1.1	0.25	0.27	
	VX333□-00	1	0.9	0.6] '.'	0.25	0.27	
,	VX324□-00	0.3	0.25	0.2	1.6	0.20	0.38	
4	VX334□-00	0.5	0.4	0.3	1.6	0.20	0.38	



 $_1$ ullet Refer to "Glossary" on page 31 for details on the max. operating pressure differential and the max. system pressure.

Fluid and Ambient Temperature


	Fluid tempe	Ambient		
Power source	Power source Solenoid valve option (symbol)			
	Nil	(°C)		
AC	-10 Note) to 60	-10 Note) to 40	-20 to 60	
DC	-10 Note) to 60	-20 to 40		



Valve Leakage


Internal Leakage / External Leakage

	<u> </u>	<u> </u>		
	Max. operating	Leakage rate		
Seal material	pressure differential	Air	Non-leak, Medium vacuum Note)	
NDD EKM	From 0 to less than 1 MPa	1 cm³/min or less	10 ⁻⁶ Pa⋅m³/sec	
NBR, FKM	1 MPa or more	2 cm³/min or less	or less	





How to Order (Solenoid Valve for Manifold)




12 VDC 100 VAC 50/60 Hz 6 2 200 VAC 50/60 Hz 240 VAC 50/60 Hz 3 8 48 VAC 50/60 Hz 110 VAC 50/60 Hz 4 220 VAC 50/60 Hz J 230 VAC 50/60 Hz 5 **24 VDC**


* Refer to Table (3) shown below for availability.



Refer to page 23 for ordering coil only.

How to Order Manifold Bases





Seal material NBR FKM

How to Order Manifold Assemblies (Example)

Enter the valve and blanking plate to be mour manifold base part number.	ited under the
* VX3111-00-1GR1 4 sets Add an "*" in f	pool for mounting. Front of the part numbers alves, etc. to be mounted.
D side (Stato) (1) (2) (3) (4) (5) - (n)	U side
	Enter the product's part number in order, counting the 1st station from the left in the m a n i f o I d arrangement, when viewing the individual port in front.
	The common port on the

-DIN terminal TS -With conduit terminal and surge

DS -DIN terminal with surge voltage suppressor -DIN terminal with light

DZ -DIN terminal with surge voltage

suppressor and light DO-For DIN terminal

(without connector, gasket is included.)

 DIN type is available with class B only. * Refer to Table (3) for available combinations between each electrical option

(S, L, Z) and rated voltage. * Surge voltage suppressor is integrated into the AC/Class B coil, as a standard.

Table (1) Model Orifice Diameter

-With conduit terminal

voltage suppressor

TZ -With conduit terminal, surge

-With conduit terminal and light

voltage suppressor and light

Solenoid	Orifice symbol (diameter)						
valve	1	2	3	4			
model	(1.5 mmø)	(2.2 mmø)	(3 mmø)	(4 mmø)			
VX31	•	•	•				
VX32	_	•	•	•			
VX33	_	•	•	•			

Table (2) Solenoid Valve Option

Ontion	Seal ma	Seal material		Cuida nin	Coil	
Option symbol	Main valve poppet	Fixed sealant	Body material	Guide pin material	insulation type	Note Note)
Nil	NBR	NBR				
V	FKM	FKM	C37	PPS	В	Non-leak (10 ⁻⁶ Pa·m³/ sec), Medium vacuum (0.1 Pa.abs), Oil-free

* Aluminum is only available as a material for the manifold base.

Note) The leakage amount (10 ⁶ Pa·m³/sec) for the "V"option are values when the differential pressure is 0.1 MPa.

Table (3) Rated Voltage Electrical Option

			Class B			
F	Rated volta	ige	S	L	Z	
AC/ DC	Voltage symbol	Voltage	With surge voltage suppressor	With light	With light and surge voltage suppressor	
	1	100 V		•		
	2	200 V	_	•		
	3	110 V		•		
AC	4	220 V	Note)	•	Note)	
	7	240 V		_		
	8	48 V		_		
	J	230 V		_		
DC	5	24 V	•	•	•	
DC	6	12 V	•	_	_	

* Class H coil is not available.

Note) Option S, Z are not available as surge voltage suppressor is integrated into the AC/Class B coil, as a standard.

≅

ᅙ Pad For Vacuum I

Construction

Dimensions

Series VX31/32/33

For Water /Single Unit


Model / Valve Specifications

N.C.

N.O.

COM.


Passage symbol



Passage symbol 2



Passage symbol






Port size	Orifice diameter	Model	Max. operatir	ng pressure diffe	erential (MPa)	Flow char	racteristics	Max. system pressure	Weight
	(mmø)		N.C.	N.O.	COM.	Av x 10 ⁻⁶ m ²	Cv converted	(MPa)	(g)
1/8	1.5	VX311□-01	1	1	0.7	1.9	0.08		
(6A)	2.2	VX312□-01	0.7	0.5	0.4	3.8	0.16		
(OA)	3	VX313□-01	0.3	0.3	0.2	5.8	0.24		380
	1.5	VX311□-02	1	1	0.7	1.9	0.08		
		VX312□-02	0.7	0.5	0.4	3.8	0.16		
	2.2	VX322□-02	1.2	1	0.7	4.6	0.19	2.0	530
1/4		VX332□-02	1.6	1.6	1				730
(8A)	3	VX313□-02	0.3	0.3	0.2	5.8	0.24		380
		VX323□-02	0.6	0.5	0.3	7.9	0.33		530
		VX333□-02	1	0.9	0.6	7.9			730
	4	VX324□-02	0.3	0.25	0.2	12	0.50		530
	4	VX334□-02	0.5	0.4	0.3	12	0.50		730
	0.0	VX322□-03	1.2	1	0.7	4.6	0.19		530
	2.2	VX332□-03	1.6	1.6	1	4.0	0.19		730
3/8	3	VX323□-03	0.6	0.5	0.3	7.9	0.33		530
(10A)	3	VX333□-03	1	0.9	0.6	7.9	0.33		730
	4	VX324□-03	0.3	0.25	0.2	10	0.50		530
	4	VX334□-03	0.5	0.4	0.3	12	0.50		730

Note) Weight of grommet type. Add 10 g for conduit, 30 g for DIN terminal, and 60 g for conduit terminal type respectively.

Also, add 60 g for VX31□□, 80 g for VX32□□ and VX33□□ respectively for bracket option.

Fluid and Ambient Temperature

	Fluid tempe	Ambient	
Power source	Solenoid valve	temperature	
	Nil, G, H	E, P	(°C)
AC	1 to 60	1 to 99	-20 to 60
DC	1 to 40	-20 to 40	



Valve Leakage

Internal Leakage / External Leakage									
Seal material	Max. operating pressure differential	Leakage rate (Water)							
NBR, FKM, EPDM	From 0 to less than 1 MPa	0.1 cm³/min or less							
NDN, FNIVI, EPDIVI	1 MPa or more	0.2 cm³/min or less							

[•] Refer to "Glossary" on page 31 for details on the max. operating pressure differential and the max. system pressure.

How to Order (Single Unit)




Table (1) Model Orifice Diameter Port Size

<u> </u>									
	Solenoid va	alve model		Orifice symbol (diameter)					
Model	VX31	VX32	VX33	1 (1.5 mma)	2 (2.2 mmø)	3 (3 mmø)	4 (4 mmø)		
				(1.5 1111116)	(2.2 1111110)	(3 11111119)	(4 1111119)		
Down	01 (1/8)	_	_	•	•	•	_		
Port symbol	02 (1/4)	_	-	•	•	•	_		
(Port size)	_	02 (1/4)	02 (1/4)	_	•	•	•		
(. 1.10.20)	_	03 (3/8)	03 (3/8)	_	•	•	•		

Table (2) Solenoid Valve Option

Option symbol	Seal m Main valve poppet	aterial Fixed sealant	Body material/ Shading coil material	Guide pin material	Coil insulation type	Note	
Nil	Nil NBR		C37	PPS	В	_	
G	, tort	NBR	Stainless steel				
E	EDDM	EPDM	C37/Cu	Stainless	Н	Heated water	
P	P EPDM		Stainless steel/Ag	steel	17	nealed Waler	
H FKM FKM		FKM	Stainless steel	PPS	В	_	

* Surge voltage suppressor is integrated into the AC/Class B coil, as a standard.

Table	Table (3) Rated Voltage Electrical Option								
В	atad valt	2000	Class B						
_ n	Rated voltage		S	L	Z				
AC/ DC	Voltage symbol	Voltage	With surge voltage suppressor	With light	With light and surge voltage suppressor				
	1	100 V		•					
	2	200 V		•					
	3	110 V		•					
AC	4	220 V	Note)	•	Note)				
	7	240 V		_					
	8	48 V		_					
	J	230 V		_					
DC	5	24 V	•	•	•				
DC	6	12 V	•	_	_				

Note) Option S, Z are not available as surge voltage suppressor is integrated into the AC/Class B coil, as a standard.

В	ated volt	000	Class H			
n	aleu voil	aye	S	L	Z	
AC/ DC	Voltage symbol	Voltage	With surge voltage suppressor	With light	With light and surge voltage suppressor	
	1	100 V	•	•	•	
	2	200 V	•	•	•	
	3	110 V	•	•	•	
AC	4	220 V	•	•	•	
	7	240 V	•		_	
	8	48 V	•	_	_	
	J	230 V	•		_	
DC	5	24 V	DC specifi	oation is n	ot available	
DC	6	12 V	DC specification is not a		ioi avaiiable.	

쥰

Construction Dimensions

Series VX31/32/33

For Oil /Single Unit


Model / Valve Specifications


N.C.


N.O.

COM.

Passage symbol









Port size	Orifice diameter	Model	Max. operatir	ng pressure diffe	erential (MPa)	Flow char	acteristics	Max. system pressure	Weight
	(mmø)		N.C.	N.O.	COM.	Av x 10 ⁻⁶ m ²	Cv converted	(MPa)	(g)
1/8	1.5	VX311□-01	1	1	0.7	1.9	0.08		
(6A)	2.2	VX312□-01	0.7	0.5	0.4	3.8	0.16		
(0A)	3	VX313□-01	0.3	0.3	0.2	5.8	0.24		380
	1.5	VX311□-02	1	1	0.7	1.9	0.08	2.0	
		VX312□-02	0.7	0.5	0.4	3.8	0.16		
	2.2	VX322□-02	1.2	1	0.7	4.6	0.19		530
1/4		VX332□-02	1.6	1.6	1	4.0			730
(8A)		VX313□-02	0.3	0.3	0.2	5.8	0.24		380
	3	VX323□-02	0.6	0.5	0.3	7.9	0.33		530
		VX333□-02	1	0.9	0.6	7.9			730
	4	VX324□-02	0.3	0.25	0.2	12	0.50		530
	4	VX334□-02	0.5	0.4	0.3	12	0.50		730
	0.0	VX322□-03	1.2	1	0.7	4.6	0.19		530
	2.2	VX332□-03	1.6	1.6	1	4.0	0.19		730
3/8	0	VX323□-03	0.6	0.5	0.3	7.9	0.33		530
(10A)	3	VX333□-03	1	0.9	0.6	7.9	0.33		730
	4	VX324□-03	0.3	0.25	0.2	12	0.50		530
	4	VX334□-03	0.5	0.4	0.3	12	0.50		730

Note) Weight of grommet type. Add 10 g for conduit, 30 g for DIN terminal, and 60 g for conduit terminal type respectively. Also, add 60 g for VX31□□, 80 g for VX32□□ and VX33□□ respectively for prackel option.

Refer to "Glossary" on page 31 for details on the max. operating pressure differential and the max. system pressure.

Fluid and Ambient Temperature

Power source	Fluid tempe Solenoid valve	erature (°C) option (symbol)	Ambient temperature
	A, H	D, N	(°C)
AC	-5 Note) to 60	-5 ^{Note)} to 120	-20 to 60
DC	-5 ^{Note)} to 40 —		-20 to 40



Valve Leakage

Internal Leakage / External Leakage

Internal Leakage / External Leakage							
Seal material	Max. operating pressure differential	Leakage rate (Oil)					
FKM	From 0 to less than 1 MPa	0.1 cm³/min or less					
LLINI	1 MPa or more	0.2 cm³/min or less					

How to Order (Single Unit)




Table (1) Model Orifice Diameter Port Size

Solenoid valve model				Orifice symbol (diameter)			
Model	V/Y21	VX31 VX32	VX33	1	2	3	4
Model	VASI		VASS	(1.5 mmø)	(2.2 mmø)	(3 mmø)	(4 mmø)
ъ.	01 (1/8)	_		•	•	•	_
Port symbol	02 (1/4)	_	_	•	•	•	_
(Port size)	_	02 (1/4)	02 (1/4)	_	•	•	•
	_	03 (3/8)	03 (3/8)	_	•	•	•

Table (2) Solenoid Valve Option

Option symbol			Body material/ Shading coil material	Guide pin material	Coil insulation type	
Α			C37	PPS	В	
Н	EKW	TIZNA FIZNA	Stainless steel	FFS		
D	FKM	FKM	C37/Cu	Stainless	Н	
N			Stainless steel/Ag	steel	Н	

^{*} The additives contained in oil are different depending on the type and manufacturers, so the durability of the seal materials will vary. For details, please consult with SMC

Table (2) Detect Valt

* Surge voltage suppressor is integrated into the AC/Class B coil, as a standard.

Table	Table (3) Rated Voltage Electrical Option							
В	ated volt	2000	Class B					
_ n	aleu voil	age	S	L	Z			
AC/ DC	Voltage symbol	Voltage	With surge voltage suppressor	With light	With light and surge voltage suppressor			
	1	100 V		•				
	2	200 V]	•				
	3	110 V		•				
AC	4	220 V	Note)	•	Note)			
	7	240 V		_				
	8	48 V						
	J	230 V		_				
DC	5	24 V	•	•	•			
DC	6	12 V	•		_			

Note) Option S, Z are not available as surge voltage suppressor is integrated into the AC/Class B coil, as a standard.

Rated voltage				Class H	
	aleu voil	aye	S	L	Z
AC/ DC			With surge voltage suppressor	With light	With light and surge voltage suppressor
	1	100 V	•	•	•
	2	200 V	•	•	•
	3	110 V	•	•	•
AC	4	220 V	•	•	•
	7	240 V	•	-	_
	8	48 V	•	_	_
	J	230 V	•		_
DC	5	24 V	DC specifi	oation is n	ot available.
	6	12 V	DC speciii	CallOff 15 11	ot available.

Specifications

For Water

ō 퉏

Steam 찟

/acuum Pad 쥰

Construction

Dimensions

Series VVX31/32/33

For Oil /Manifold

Solenoid Valve for Manifold / Valve Specifications


N.C.

N.O.


COM.




Passage symbol







Passage symbol




Orifice diameter	Model	Max. operating pressure differential (MPa)		Flow characteristics		Max. system pressure	
(mmø)		N.C.	N.O.	COM.	Av x 10 ⁻⁶ m ²	Cv converted	(MPa)
1.5	VX311□-00	1	1	0.7	1.9	0.08	
	VX312□-00	0.7	0.5	0.4	3.8	0.16	
2.2	VX322□-00	1.2	1	0.7	4.0	0.10	1
	VX332□-00	1.6	1.6	1	4.6	0.19	
	VX313□-00	0.3	0.3	0.2	5.8	0.24	2.0
3	VX323□-00	0.6	0.5	0.3	7.0	0.22	
	VX333□-00	1	0.9	0.6	7.9	0.33	
4	VX324□-00	0.3	0.25	0.2	10	0.50	
4	VX334□-00	0.5	0.4	0.3	12	0.50	



[•] Refer to "Glossary" on page 31 for details on the max. operating pressure differential and the max system pressure

Fluid and Ambient Temperature

Power source	Fluid tempe Solenoid valve	Ambient temperature	
	Α	D	(°C)
AC	-5 Note) to 60	-5 Note) to 120	-20 to 60
DC	-5 ^{Note)} to 40 —		-20 to 40



Valve Leakage

	Internal Leakage / External Leakage							
	Seal material	Max. operating pressure differential	Leakage rate (Oil)					
	FKM	From 0 to less than 1 MPa	0.1 cm³/min or less					
		1 MPa or more	0.2 cm³/min or less					

Specifications

₹

F٥

Water

For

ō

퉏


Steam

ᅙ

Vacuum Pad

쥰

How to Order (Solenoid Valve for Manifold)



Number of

manifolds

10 10 stations

2 stations

02

- * Refer to Table (3) for available combinations between each
 - electrical option (S, L, Z) and rated voltage. * Surge voltage suppressor is integrated into the AC/Class B
 - coil, as a standard.

Table (1) Model Orifice Diameter

	Solenoid	Orifice symbol (diameter)					
	valve	1	2	3	4		
	model	(1.5 mmø)	(2.2 mmø)	(3 mmø)	(4 mmø)		
I	VX31	•	•	•			
ĺ	VX32	_	•	•	•		
	VX33	_	•	•	•		

Option	Seal m	aterial	Body material/	Guide pin	Coil	
symbol	Main valve poppet	Fixed sealant	Shading coil material	Snading coll material II		insulation type
Α	FKM	FIZM	C37	PPS	В	
D	FNM	FKM	C37/Cu	Stainless steel	Н	

- * Aluminum is only available as a material for the manifold base.
- * The additives contained in oil are different depending on the type and manufacturers, so the durability of the seal materials will vary. For details, please consult with SMC.

Table (3) Rated Voltage Electrical Entry Electrical Option

ubic	(5) 114	ieu vo	nage	LICCIII	cai Liii	y	Cuicai	Option
В	ated volt	000		Class B			Class H	
_ n	aleu voil	aye	S	L	Z	S	L	Z
AC/ DC	Voltage symbol	Voltage	With surge voltage suppressor	With light	With light and surge voltage suppressor	With surge voltage suppressor	With light	With light and surge voltage suppressor
	1	100 V		•		•	•	•
	2	200 V		•		•	•	•
	3	110 V		•		•	•	•
AC	4	220 V	Note)	•	Note)	•	•	•
	7	240 V		_		•	_	_
	8	48 V		_		•	_	_
	J	230 V		_		•	_	_
DC	5	24 V	•	•	•	DC sp	ecificatio	n is not
DC	6	12 V	•	_	_	availab	ole.	

Note) Option S, Z are not available as surge voltage suppressor is integrated into the AC/Class B coil, as a standard. 13

valve model	1 (1.5 mmø)	2	3 (3 mmø)	4 (4 mmø)
VX31	(1.5 111118)	(2.2 IIIII0)	(3 111119)	(4 mmb)
VX32	_	•	•	•
VX33	_	•	•	•
Table (2)	Solenoid	Valve O	ption	

• Blanking plate part no.

VVX32

VVX33

Manifold base

For VX31 VVX31-4A-F For VX32/33: VVX32-4A-F

Seal material: FKM

* Indicating numbers shown below are for common ports.

3

How to Order Manifold Assemblies (Example)

Suffix

Oil-free spec.

Port size (Individual port)

SUP port | EXH port

* Common port sizes are all Rc 1/4.

Nil

Rc 1/8

Rc 1/4

1

Type

N.C

N.O.

2

Enter the valve and blanking plate to be mounted under the manifold base part number. Example VVX311-05-1 1 set "*" is the symbol for mounting. Add an "*" in front of the part numbers * VX3111A-00-1GR1.. 4 sets for solenoid valves, etc. to be mounted. * VVX31-4A-F..... 1 set D side (Station)- (1)----(2)----(3)--(4)----(5)--(n) U side Enter the product's part number in order, counting the 1st station from the left in the manifold arrangement, viewing the individual port in front. The common port on the

SVK

right side is plugged.

Construction


Dimensions

For Steam /Single Unit

Model / Valve Specifications

COM.

Passage symbol





Port size	Orifice diameter (mmø)	Model	Max. operating pressure differential (MPa)	Flow cha	racteristics	Max. system pressure	Weight
	(1111119)		COM.	Av x 10 ⁻⁶ m ²	Cv converted	(MPa)	(g)
1/8	1.5	VX3114-01	0.7	1.9	0.08		
(6A)	2.2	VX3124-01	0.4	3.8	0.16		
(OA)	3	VX3134-01	0.2	5.8	0.24		380
	1.5	VX3114-02	0.7	1.9	0.08		
		VX3124-02	0.4	3.8	0.16		
	2.2	VX3224-02	0.7	4.6	0.19		530
1/4		VX3324-02	1	4.6	0.19		730
(8A)		VX3134-02	0.2	5.8	0.24		380
	3	VX3234-02	0.3	7.9	0.33	10	530
		VX3334-02	0.6	7.9	0.33	1.0	730
	4	VX3244-02	0.2	12	0.50		530
	4	VX3344-02	0.3	12	0.50		730
	0.0	VX3224-03	0.7	4.6	0.19		530
	2.2	VX3324-03	1	4.6	0.19		730
3/8	3	VX3234-03	0.3	7.9	0.33		530
(10A)	3	VX3334-03	0.6	7.9	0.33		730
	4	VX3244-03	0.2	10	0.50		530
	4	VX3344-03	0.3	12	0.50		730

Note) Weight of grommet type. Add 10 g for conduit, 30 g for DIN terminal, and 60 c for conduit terminal type respectively. Also, add 60 g for VX31□□, 80 g for VX32□□ and VX33□□ respectively for bracket option.

• Refer to "Glossary" on page 31 for details on the max. operating pressure differential and the max. system bressure.

Fluid and Ambient Temperature

Power source	Fluid temperature (°C) Solenoid valve option (symbol)	Ambient temperature
	S, Q	(°C)
AC	183	-20 to 60

Valve Leakage

Turro zounago	
Internal Leakage	
Seal material	Leakage rate (Air)
FFKM	150 cm³/min or less
External Leakage	
Seal material	Leakage rate (Air)
PTFE	1 cm³/min or less



How to Order (Single Unit)




Table (1) Model Orifice Diameter Port Size

	Solenoid va	alve model		(Orifice symb	ol (diameter	·)
Model	VX31	VX32	VX33	1 (1.5 mmø)	2 (2.2 mmø)	3 (3 mmø)	4 (4 mmø)
D .	01 (1/8)	_	_	•	•	•	_
Port symbol	02 (1/4)	_	_	•	•	•	_
(Port size)	_	02 (1/4)	02 (1/4)	_	•	•	•
(. 0.1 0.20)	_	03 (3/8)	03 (3/8)	_	•	•	•

Table (2) Solenoid Valve Option

· a.b.o (=)	00.00.4	Tuite op			
Ontion	Seal m	naterial	Body material/	Cuida nin	Coil
Option symbol	Main valve poppet	Fixed sealant	Shading coil material	Guide pin material	insulation type
S	FFKM	PTFE	C37/Cu	Stainless	Н
Q	FFKIVI	PIFE	Stainless steel/Ag	steel	

Solenoid coil AC/Class H only

Table (3) Rated Voltage Ele	ctrical Option
-----------------------------	----------------

Iabic	(5) 114	leu voii	age Liec	trical O	Puon
В	ated volt	000		Class H	
	aleu voil	aye	S	L	Z
AC/ DC	Voltage symbol	Voltage	With surge voltage suppressor	With light	With light and surge voltage suppressor
	1	100 V	•	•	•
	2	200 V	•	•	•
	3	110 V	•	•	•
AC	4	220 V	•	•	•
	7	240 V	•	-	_
	8	48 V	•	_	_
	J	230 V	•	_	_
DC	5	24 V	DC aposifi	aation is n	ot available.
DC	6	12 V	DC speciii	cation is n	ot available.

Construction

Dimensions

For Vacuum Pad / Single Unit Series VXV31/32/33


- Vacuum circuit side is suited for a large orifice. Supply pressure side is suited for high pressure and a vacuum pad.
- Construction and dimensions are the same as the VX3 series


Model / Valve Specifications

N.C.

N.O.


Passage symbol (example)








		diameter			pressure*			Flow char	acteristics			Max.	Note)
Port size	(mr	nø)	Model	(MI	Pa)	Pa	assage: 1¢	⇒2	Pa	ıssage: 2¢	⇒3	system	Weight
1 011 0120		Port 3 side	Model	Port 1 side	Port 3 side	C[dm ³ / (s⋅bar)]	b	Cv	C[dm ³ / (s·bar)]	b	Cv	pressure (MPa)	(g)
1/8	3	1.5	VXV3130-01	Low vacuum	0 to 0.5	0.82	0.20	0.20	0.29	0.32	0.08		
(6A)	1.5	3	VXV3132-01	0 to 0.5	Low vacuum	0.29	0.32	0.08	0.82	0.20	0.20		380
	3	1.5	VXV3130-02	Low vacuum	0 to 0.5	0.82	0.20	0.20	0.29	0.32	0.08		360
	1.5	3	VXV3132-02	0 to 0.5	Low vacuum	0.29	0.32	0.08	0.82	0.20	0.20		
1/4	4	2.2	VXV3240-02	Low vacuum	0 to 0.5	1.6	0.20	0.38	0.64	0.40	0.17		530
(8A)	4	2.2	VXV3340-02	LOW Vacuuiii	0 to 0.9	1.0	0.20	0.56	0.04	0.40	0.17	2.0	730
	2.2	4	VXV3242-02	0 to 0.5	Low vacuum	0.64	0.40	0.17	1.6	0.20	0.38	2.0	530
	2.2	4	VXV3342-02	0 to 0.9	LOW Vacuum	0.04	0.40	0.17	1.0	0.20	0.50		730
	4	2.2	VXV3240-03	Low voorum	0 to 0.5	1.6	0.20	0.38	0.64	0.40	0.17		530
3/8	4	2.2	VXV3340-03	Low vacuum	0 to 0.9	1.0	0.20	0.36	0.04	0.40	0.17		730
(10A)	2.2	4	VXV3242-03	0 to 0.5	Lowysoum	0.64	0.40	0.17	1.6	0.20	0.38		530
	2.2	4	VXV3342-03	0 to 0.9	Low vacuum	0.04	0.40	0.17	1.0	0.20	0.36		730



[•] Refer to "Glossary" on page 31 for details on the max operating pressure differential and the max system pressure

Fluid and Ambient Temperature

Power source	Fluid temperature (°C)	Ambient temperature (°C)
AC	-10 Note) to 60	-20 to 60
DC	-10 Note) to 60	-20 to 40



Valve Leakage


Internal Leakage / External Leakage

Seal material	Leakage rate Note)	
Seai materiai	Air	
NBR. FKM	1 cm³/min or less	



^{*}Low vacuum Up to 1.3 x 10°Pa

How to Order (Single Unit)



* Refer to Table (3) for available combinations between each electrical option (S, L, Z) and rated voltage

* Surge voltage suppressor is integrated into the AC/Class B coil, as a standard

Table (1) Model Orifice Diameter Port Size

	Solenoid v	alve model		Orifice symbol	(diameter) Note)	
Model	VXV31	VXV32	VXV33	3 (1.5/3 mmø)	4 (2.2/4 mmø)	
Doub	01 (1/8)	_	_	•	_	
Port symbol	02 (1/4)	_	_	•	_	
(Port size)	_	02 (1/4)	02 (1/4)	_	•	
(* 511 5125)	_	03 (3/8)	03 (3/8)	_	•	

Note) The orifice diameter shown above are for the supply pressure side/

Table (2) Solenoid Valve Option

Option	Seal m	aterial		Guide pin	Coil
symbol	Main valve poppet	Fixed sealant	Body material	material	insulation type
Nil	NBR	NBR	C37		
Α	FKM	FKM	U37	PPS	В
G	NBR	NBR	Stainless steel	FF3	ا ا
Н	FKM	FKM	Stainless steel		

Table (3) Rated Voltage Electrical Option

	` '		·· J ·		- P
Rated voltage			Class B		
_ n	aleu voil	aye	S	L	Z
AC/ DC	Voltage symbol	Voltage	With surge voltage suppressor	With light	With light and surge voltage suppressor
	1	100 V		•	
	2	200 V		•	
	3	110 V		•	
AC	4	220 V	Note)	•	Note)
	7	240 V		ı	
	8	48 V		l	
	J	230 V		_	
DC	5	24 V	•	•	•
DC	6	12 V	•	_	_

Note) Option S, Z are not available as surge voltage suppressor is integrated into the AC/Class B coil, as a standard.

* Class H coil is not available.

For Vacuum Pad / Manifold Series VVXV31/32/33


• Construction and dimensions are the same as those of the VVX3 series.


Model / Valve Specifications


N.C.

N.O.


Passage symbol (example)








	diameter mø)	Madal		pressure* Pa)	Р	assage: 1⇔		acteristics	assage: 2⇔	3	Max. system
Port 1 side	Port 3 side	Model	Port 1 side	Port 3 side	Oral3/	b	Cv	C[dm ³ / (s·bar)]	b	Cv	pressure (MPa)
3	1.5	VXV3131-00	Low vacuum	0 to 0.5	0.82	0.20	0.20	0.29	0.32	0.08	
1.5	3	VXV3133-00	0 to 0.5	Low vacuum	0.29	0.32	0.08	0.82	0.20	0.20	1
4	2.2	VXV3241-00 VXV3341-00	Low vacuum	0 to 0.5 0 to 0.9	1.6	0.20	0.38	0.64	0.40	0.17	2.0
2.2	4	VXV3243-00 VXV3343-00	0 to 0.5 0 to 0.9	Low vacuum	0.64	0.40	0.17	1.6	0.20	0.38	



Refer to "Glossary" on page 31 for details on the max. operating pressure differential and the max system pressure

Fluid and Ambient Temperature


Power source	Fluid temperature (°C)	Ambient temperature (°C)
AC	-10 Note) to 60	-20 to 60
DC	-10 Note) to 60	-20 to 40




Valve Leakage

Internal Leakage / External Leakage

Seal material	Leakage rate Note)				
Searmaterial	Air				
NBR, FKM	1 cm³/min or less				
Note) Value when air pressure is applied					




How to Order (Solenoid Valve for Manifold)




1	100 VAC 50/60 Hz	6	12 VDC
2	200 VAC 50/60 Hz	7	240 VAC 50/60 Hz
3	110 VAC 50/60 Hz	8	48 VAC 50/60 Hz
4	220 VAC 50/60 Hz	J	230 VAC 50/60 Hz
5	24 VDC		


* Refer to Table (3) shown below for availability




How to Order Manifold Bases




Blanking plate part no.



How to Order Manifold Assemblies (Example)






-With conduit terminal

TS -With conduit terminal and surge voltage suppressor

TL -With conduit terminal and light TZ -With conduit terminal, surge voltage suppressor and light



- -DIN terminal
- DS -DIN terminal with surge voltage suppressor
- -DIN terminal with light
- DZ -DIN terminal with surge voltage suppressor and light
- DO -For DIN terminal (without connector. gasket is included.)
- * DIN type is available with class B only.
- * Refer to Table (3) for available combinations between each electrical option (S, L, Z) and rated voltage.
- * Surge voltage suppressor is integrated into the AC/Class B coil, as a standard.

Table (1) Model Orifice Diameter

145.5 (1)	Table (1) incus. Clines Diam.				
Solenoid	Orifice symbol	(diameter) Note)			
valve	3	4			
model	(1.5/3 mmø)	(2.2/4 mmø)			
VXV31	•	_			
VXV32	_	•			
VXV33	_	•			

Note) The orifice diameter shows the supply pressure side/vacuum side.

Table (2) Solenoid Valve Option

Option	Seal m	naterial		Guide	Coil	
symbol	Main valve	Fixed	Body material		insulation	
Cy20.	poppet	sealant		material	type	
Nil	NBR	NBR	C37	PPS	В	
Α	FKM	FKM	037	FFS	Ь	

^{*} Aluminum is only available as a material for the manifold base.

Table (3) Pated Voltage Floatrical Option

rable (3) Rated Voltage Electrical Option							
	atad valt		Class B				
_ n	ated volt	age	S	L	Z		
AC/ DC	Voltage symbol	Voltage	With surge voltage suppressor	With light	With surge voltage suppressor		
	1	100 V		•			
	2	200 V		•			
	3	110 V		•			
AC	4	220 V	Note)	•	Note)		
	7	240 V		_			
	8	48 V		I			
	J	230 V	Γ	_			
DC	5	24 V	•	•	•		
DC	6	12 V	•	_	_		

Class H coil is not available.

Note) Option S, Z are not available as surge voltage suppressor is integrated into the AC/Class B coil, as a standard.

Specifications

₹ 퉏

Water For

≅ 퉏

Steam

ᅙ

/acuum F ē


Construction

Series VX31/32/33

For Air, Water, Oil, Steam

Construction

Single unit Body material C37 Stainless steel



Component Parts


NI-	D	Mate	erial	
No.	Description	Standard	Option	
4	Body	C37	Stainless steel	
ာ	Tube assembly Note)	Stainless steel, Cu	Stainless steel, Ag	
3	Armature assembly	Stainless steel, C36, PTFE (NBR)	Stainless steel, PTFE (FKM, EPDM, FFKM)	
4	Return spring	Stainles	ss steel	
5	Nut	C37	C37/Ni plated	
٩	Solenoid coil	Class B molded	Class H molded	
7	O-ring	(NBR)	(FKM, EPDM, PTFE)	
9	Clip	S	K	
9	Guide pin assembly	PPS, C36 (NBR)	Stainless steel (FKM, EPDM, FFKM)	
10	Support spring	Stainles	ss steel	
11	O-ring	(NBR)	(FKM, EPDM, PTFE)	
12	Plate	Stainless steel		

The materials in parentheses are the seal materials.

Note) Cu and Ag are not applicable to the DC spec and to the AC spec with built-in full-wave rectifier.

Manifold

Base material: Aluminum Manifold body material: C37



Component Parts

No.	Description	Mate	erial		
INO.	Description	Standard	Option		
	Manifold body	C3	7		
3	Tube assembly Note)	Stainless steel, Cu			
3	Armature assembly	Stainless steel, C36, PTFE (NBR)	Stainless steel, PTFE (FKM, EPDM, FFKM)		
1	Return spring	Stainless steel			
5	Nut	C37	C37/Ni plated		
٩	Solenoid coil	Class B molded	Class H moldec		
7	O-ring	(NBR)	(FKM, EPDM)		
Я	Clip	SI	<		
9	Guide pin assembly	PPS, C36 (NBR)	Stainless steel (FKM, EPDM)		
٩0	Support spring	Stainles	s steel		
11	O-ring	(NBR)	(FKM, EPDM)		
15	Plate	Stainles	s steel		
13	Gasket	(NBR)	(FKM, EPDM)		
⁴4	Base	Aluminum			

The materials in parentheses are the seal materials.


Note) Cu is not applicable to the DC spec and to the AC spec with built-in tull-wave rectifier




Dimensions Single Unit / Body Material C37, Stainless Stee

Normally closed (N.C.) VX31□0/VX32□0/VX33□0
Normally open (N.O.) VX31□2/VX32□2/VX33□2
Common (COM.) VX31□4/VX32□4/VX33□4


Grommet: G




DIN terminal: D




With bracket



Conduit: C



Conduit terminal T



														(mm)		
Ī	Model	0		Electrical entry (AC/Class B)												
ı	iviouei	Orifice diameter	Port size	Gromn		Conduit DIN			l term	inal	Co	onduit	duit terminal			
	N.C., N.O., COM.	diameter	Р	J	K	J	K	J	K	М	J	K	M	N		
	VX31 □□	ø1.5, ø2.2, ø3	1/8	30	46	48.5	41	65.5	42	E0 E	100.5	44	69.5	91.5		
	VX31 □□	ø1.5, ø2.2, ø3	1/4	30	40	46.5	41	05.5	42	53.5	100.5	41	09.5	91.5		
	VX32□□	ø2.2, ø3, ø4	1/4, 3/8	33	56	51.5	51	68.5	52	56.5	103.5	51	72.5	105		
	VY33□□	a22 a3 a4	1/4 3/8	36	64.5	54	59.5	71	60.5	59	106	59.5	75	113		

																									(mm)
Model	0 ''	.			В						Electrical entry (DC, AC/Class H)									Dro	alcat i		tina		
Model	Orifice diameter	Port size	Α	·	•	С	D	Ε	F	Н	Gron	nmet	Cor	nduit	DIN	I termi	inal	Co	onduit	termi	nal	Bra	скет і	moun	ting
N.C., N.O., COM.	ulametei	Р		B ₁	B ₂						J	K	J	K	J	K	M	J	K	M	N	Ø	R	S	Т
VX31□□	ø1.5, ø2.2, ø3	1/8	00	36	18	76.5	30	19	10.5	27	19.5	F0	40	42.5	F0 F	42	46.5	92	42.5	61	93	17.5	40	F0	75.5
VX31□□	ø1.5, ø2.2, ø3	1/4	22	41	20.5	/ 6.5	30	19	19.5	21	19.5	50	40	42.5	58.5	42	40.5	92	42.5	01	93	17.5	40	50	75.5
VX32□□	ø2.2, ø3, ø4	1/4, 3/8	24	42	21	90	35	22	22.5	32	22.5	60	43	52.5	61.5	52	49.5	95	52.5	64	106.5	21	47	57	89
VX33□□	ø2.2, ø3, ø4	1/4, 3/8	24	42	21	98	40	22	25	36	25.5	68.5	46	61	64	60.5	52	98	61	66.5	114.5	21	47	57	97

Specifications

For Air

For Water

For Oil

For Steam

For Vacuum Pad


Construction


Series VVX31/32/33

For Air, Oil / Manifold

Dimensions Manifold / Base Material Aluminum

Normally closed (N.C.)
Normally open (N.O.) VVX31/VVX32/VVX33
Common (COM.)







										(mm)			
Model	Dimen-		n (stations)										
Model	sion	2	3	4	5	6	7	8	9	10			
VVX31	L ₁	96	132	168	204	240	276	312	348	384			
VVASI	L2	84	120	156	192	228	264	300	336	372			
VVX32	L ₁	126	172	218	264	310	356	402	448	494			
VVX33	L ₂	108	154	200	246	292	338	384	430	476			

																						(mm)
																Electri	cal ent	ry (DC,	AC/CI	Class H)		
Model	Α	В	С	D	E	F	Н	J	K	L	M	N	Q	Grommet	Cor	nduit	DII	N termi	nal	Con	duit terr	ninal
														R	S	Т	Т	U	٧	W	X	Υ
VVX31	40	20	9	22	6.5	33	24	26	36	6	49	19.5	80.5	19.5	40	45.5	45	58.5	46.5	92	61	97
VVX32	44	22	10	24	8.5	34	25	31	46	9	55	22.5	91	22.5	43	54	53.5	61.5	49.5	95	64	107.5
VVX33	44	22	10	24	8.5	34	25	31	46	9	55	25	99.5	25.5	46	62	61.5	64	52	98	66.5	1.6

									(mm)			
	Electrical entry (AC/Class B)											
Model	Grommet	nmet Conduit DIN termina				nal	Cond	Conduit terminal				
	R	S	Т	Т	U	٧	W	Х	Υ			
VVX31	30	48.5	44	45	65.5	53.5	100.5	69.5	95.5			
VVX32	33	51.5	52.5	53.5	68.5	56.5	103.5	72.5	106			
VVX33	36	54	60.5	61.5	71	59	106	75	114.5			

DC





* Refer to Table (1) for available combinations between each electrical option and rated voltage


AC/Class H coil

-With conduit terminal

TL -With conduit terminal and light


TS -With conduit terminal and surge voltage suppressor

TZ -With conduit terminal, surge voltage suppressor and




* Refer to Table (1) for available combinations between each electrical option and rated voltage

AC/Class B coil (Built-in full-wave rectifier type)



Electrical entry



- * Refer to Table (1) for available combinations between each electrical option and rated voltage
- * Surge voltage suppressor is integrated into the AC/Class B coil, as a standard.

Table (1) Rated Voltage Electrical Option

	<u> </u>	atou ve			icui O			
В	ated volt	2000		Class B			Class H	
_ n	aleu voil	age	S	L	Z	S	L	Z
AC/ DC	Voltage symbol	Voltage	With surge voltage suppressor	With light	With light and surge voltage suppressor	With surge voltage suppressor	With light	With light and surge voltage suppressor
	1	100 V		•		•	•	•
	2	200 V		•		•	•	•
	3	110 V		•		•	•	•
AC	4	220 V	— Note)	•	Note)	•	•	•
	7	240 V		I		•	I	_
	8	48 V				•		_
	J	230 V		I		•	I	_
DC	5	24 V	•	•	•	DC sp	ecification	n is not
DC	6	12 V		_	_	availab	ole.	

Note) Option S, Z are not available since a surge voltage suppressor is integrated into the AC/Class B coil, as a standard

* When changing coils, AC/DC are not interchangeable with each other, and Class B and H coils are also not interchangeable with each other.

Specifications

For Water

≅ [편

Steam 퉏

For Vacuum Pad

Construction

Dimensions

Replacement Parts

• Name plate part no.




• Clip part no.


For VX31 VX021N-10

For VX32: VX022N-10

For VX33: VX023N-10



• DIN connector part no.



• Gasket part no. for DIN connector

VCW20-1-29-1

(How to indicate flow characteristics)

1. Indication of flow characteristics

Indication of the flow characteristics in specifications for equipment such as solenoid valve, etc. is depending on "Table (1)".

Table (1) Indication of Flow Characteristics

Corresponding equipment	Indication by international standard	Other indications	Standards conforming to
Equipment for	C, b	_	ISO 6358: 1989 JIS B 8390: 2000
pneumatics	_	S	JIS B 8390: 2000 Equipment: JIS B 8373, 8374, 8375, 8379, 8381
		Cv	ANSI/(NFPA)T3.21.3: 1990
Equipment for controlling	Av	_	IEC60534-2-3: 1997 JIS B 2005: 1995
process fluids	_	Cv	Equipment: JIS B 8471, 8472, 8473

2. Equipment for pneumatics

2.1 Indication according to the international standards

(1) Standards conforming to

ISO 6358: 1989 : Pneumatic fluid power—Components using compressible fluids—

Determination of flow-rate characteristics

JIS B 8390: 2000: Pneumatic fluid power—Components using compressible fluids—

How to test flow-rate characteristics

(2) Definition of flow characteristics

Flow rate characteristics are indicated as a result of a comparison between sonic conductance C and critical pressure ratio b.

Sonic conductance C: Values which divide the passing mass flow rate of an equipment in a choked flow condition by the

product of the upstream absolute pressure and the density in the standard condition.

Critical pressure ratio b: It is the pressure ratio which will turn to the choke flow (downstream pressure/upstream pressure)

when it is smaller than this values. (critical pressure ratio)

Choked flow : It is the flow in which the upstream pressure is higher than the downstream pressure and where

sonic speed in a certain part of an equipment is reached.

Gaseous mass flow rate is in proportion to the upstream pressure and not dependent on the

downstream pressure. (choked flow)

Subsonic flow : Flow greater than the critical pressure ratio

Standard condition : Air in a temperature state of 20C, absolute pressure 0.1 MPa (= 100 kPa = 1 bar), relative humidity

65%

It is stipulated by adding the abbreviation (ANR) after the unit depicting air volume.

(standard reference atmosphere)

Standard conforming to: ISO 8778: 1990 Pneumatic fluid power—Standard reference atmosphere, JIS B 8393: 2000: Pneumatic fluid power—Standard reference atmosphere

(3) Formula of flow rate

It can be indicated by the practical unit as following.

When

$$\frac{P_{2} + 0.1}{P_{1} + 0.1}$$
 b, choked flow

$$Q = 600 \times C (P1 + 0.1) \sqrt{\frac{293}{273 + t}}$$
(1)

When

$$\frac{P2 + 0.1}{P1 + 0.1} > b$$
, subsonic flow

$$Q = 600 \times C (P_1 + 0.1) \sqrt{1 - \left[\frac{P_2 + 0.1}{P_1 + 0.1} - b \right]^2} \sqrt{\frac{293}{273 + t}}$$
 (2)

Q : Air flow rate [dm³/min (ANR)], dm³ (Cubic decimeter) of SI unit are also allowed to described by ℓ (liter). 1 dm³ = 1 ℓ.



C Sonic conductance [dm³/(s·bar)]

b Critical pressure ratio [—]

P1 Upstream pressure [MPa]

P2 Downstream pressure [MPa]

t Temperature [C]

Note) Formula of subsonic flow is the elliptic analogous curve.

Flow characteristics curve is indicated in the Graph (1 For details, please use SMC's "Energy Saving Program"


Example)

Obtain the air flow rate for $P_1 = 0.4$ [MPa], $P_2 = 0.3$ [MPa], t = 20 [C] when a solenoic valve is performed in C = 2 [dm³/(s·bar)] and b = 0.3.

According to formula 1, the maximum flow rate = $600 \times 2 \times (0.4 + 0.^{\circ}) \times \sqrt{\frac{293}{273 + 20}} = 600 \text{ [dm}^3/\text{min (ANR)]}$

Pressure ratio =
$$\begin{cases} 0.3 + 0.1 \\ 0.4 + 0.1 \end{cases} = 0.8$$

Based on the Graph (1), it is going to be 0.7 if it is read by the pressure ratio as 0.8 and the flow ratio to be b = 0.3 Hence, flow rate = Max. flow x flow ratio = $600 \times 0.7 = 420 \text{ [dm}^3/\text{min (ANR)]}$



Graph (1) Flow characteristics line

(4) Test method

By attaching a test equipment with the test circuit indicated in Fig. (1) while maintaining to a certain amount which does not let the upstream pressure go down below 0.3 MPa, measure the maximum flow to be saturated in the first place. Next measure this flow rate at 80%, 60%, 40%, 20% and the upstream and downstream pressure. And then obtain the sonic conductance C from this maximum flow rate. Besides that, substitute each data of others for the formula of subsonic flow in order to find b, then obtain the critical pressure ratio b from that average.




Fig. (1) Test circuit based on ISO 6358, JIS B 8390



2.2 Effective area S

(1) Standards conforming to

JIS B 8390: 2000: Pneumatic fluid power—Components using compressible fluids—

Determination of flow rate characteristics

Equipment standards: JIS B 8373: 2 port solenoid valve for pneumatics

JIS B 8374: 3 port solenoid valve for pneumatics

JIS B 8375: 4 port, 5 port solenoid valve for pneumatics

JIS B 8379: Silencer for pneumatics

JIS B 8381: Fittings of flexible joint for pneumatics

(2) Definition of flow characteristics

Effective area S: is the cross-sectional area having an ideal throttle without friction deduced from the calculation of the pressure changes inside an air tank or without reduced flow when discharging the compressed air in a choked flow, from an equipment attached to the air tank. This is the same concept representing the "easy to run through" as sonic conductance C (effective area).

(3) Formula of flow rate

When

$$\frac{P_{2} + 0.1}{P_{1} + 0.1}$$
 0.5, **choked flow**

$$Q = 120 \times S (P_{1} + 0.1) \sqrt{\frac{293}{273 + t}}$$
(3)

When

$$\frac{P2 + 0.1}{P1 + 0.1} > 0.5$$
, subsonic flow $Q = 240 \times S \sqrt{(P2 + 0.1)(P1 - P2)} \sqrt{\frac{293}{273 + t}}$ (4)

Conversion with sonic conductance *C*:

 $S = 5.0 \times C$ (5)

Q: Air flow rate[dm³/min(ANR)], dm³ (cubic decimeter) of SI unit is good to be described by ℓ (liter), too. 1 dm³ = 1 ℓ

S: Effective area [mm²]

P1: Upstream pressure [MPa]

P2: Downstream pressure [MPa]

: Temperature [C]

Note) Formula for subsonic flow (4) is only applicable when the critical pressure ratio b is the unknown equipment. In the formula by sonic conductance C(2), it is the same formula when b = 0.5.

(4) Test method

By attaching the equipment for testing with the test circuit shown in Fig. (2), discharge air into the atmosphere until the pressure inside the air tank goes down to 0.25 MPa (0.2 MPa) from an air tank filled with compressed air of a certain pressure (0.5 MPa) which does not go down below 0.6 MPa. At this time, measure the discharging time and the residual pressure inside the air tank which had been left until it turned to be the normal values, and then determine the effective area S by using the following formula. The volume of air tank should be selected within the specified range by corresponding to the effective area of the equipment being tested. In the case of JIS B 8373, 8374, 8375, 8379, 8381, the pressure values are in parentheses and the coefficient of formula is 12.9.

$$S = 12.1 \frac{V}{t} \log_{10} \left(\frac{Ps + 0.1}{P + 0.1} \right) \sqrt{\frac{293}{T}} \dots (6)$$

S: Effective area [mm²]

V : Air tank capacity [dm3]

: Discharging time [s]

Ps: Pressure inside air tank

before discharging [MPa]

: Residual pressure inside air tank after discharging [MPa]

: Temperature inside air tank before discharging [K]




Fig. (2) Test circuit based on JIS B 8390



2.3 Flow coefficient Cy factor

The United States Standard ANSI/(NFPA)T3.21.3:1990: Pneumatic fluid power—Flow rating test procedure and reporting method for fixed orifice components

defines the Cv factor of flow coefficient by the following formula which is based on the test conducted by the test circuit analogous to ISO 6358.

$$Cv = \frac{Q}{114.5 \sqrt{\frac{P(P_2 + P_a)}{T_1}}}$$
 (7)

P Pressure drop between the static pressure tapping ports [bar]

P1 Pressure of the upstream tapping port [bar gauge]

P2 Pressure of the downstream tapping port [bar gauge]: P2 = P1 − P

Q Flow rate [dm³/s standard condition]

Pa Atmospheric pressure [bar absolute]

T1 Test conditions of the upstream absolute temperature [K]

is $< P1 + Pa = 6.5 \, 0.2$ bar absolute, $T1 = 297 \, 5$ K, 0.07 bar $P \, 0.14$ bar

This is the same concept as effective area A which ISO6358 stipulates as being applicable only when the pressure drop is smaller than the upstream pressure and the compression of air does not become a problem

3. Equipment for process fluids

(1 Standards conforming to

IEC60534-2-3: 1997: Industrial process control valves. Part 2: Flow capacity, Section Three-Test procedures

JIS B 2005: 1995: Test method for the flow coefficient of a valve

Equipment standards: JIS B 8471 Regulator for water

JIS B 8472: Solenoid valve for steam JIS B 8473: Solenoid valve for fuel oil

(2) Definition of flow characteristics

Av factor. Value of the clean water flow rate represented by m³/s which runs through a valve (equipment for test) when the pressure difference is 1 Pa. It is calculated using the following formula.

$$Av = Q^{\sqrt{\frac{\rho}{P}}}$$
 (8)

Av Flow coefficient [m²]

Q Flow rate [m³/s]

P Pressure difference [Pa]

ρ Density of fluid [kg/m³]

(3) Formula of flow rate

It is described by the known unit. Also, the flow characteristics line shown in the Graph (2)

In the case of liquid:

$$Q = 1.9 \times 10^6 Av \sqrt{\frac{P}{G}}$$
 (9)

Q Flow rate [ℓ/min]

Av Flow coefficient [m²]

P Pressure difference [MPa]

G Relative density [water = 1]

In the case of saturated aqueous vapor:

$$Q = 8.3 \times 10^6 Av \sqrt{P(P_2 + 0.1)}$$
 (*0)

Q Flow rate [m³/s]

Av Flow coefficient [m²]

P Pressure difference [Pa]

 P_1 Relative density [MPa]: $P = P_1$ P_2

P2 Relative density [MPa]

Conversion of flow coefficient:


 $AV = 28 \times 10^{-6} \text{ KV} = 24 \times 10^{-6} \text{ CV} \dots (1)$

Here

KV factor: Value of the clean water flow rate represented by the m^{5/h} which runs through the valve at 5 to 40°C when the pressure difference is 1 bar

Cv factor (Reference values): It is the figures representing the flow rate of clean water by US gal/min which runs through the valve at 60°F, when the pressure difference is 1 lbf/in² (psi).

Values of pneumatic Kv are different from Cv because the testing method is different from each other.



Graph (2) Flow characteristics line

Example 1

Obtain the pressure difference when water 15 [ℓ /min] runs through the solenoid valve with an $AV = 45 \times 10^{-6}$ [m²] Since Qo = 15/45 = 0.33 [/min], according to the Graph (2), if reading P when Qo is 0.33, it will be 0.031 [MPa].

Example 2)

Obtain the flow rate of saturated aqueous vapor when $P_1 = 0.8$ [MPa], P = 0.008 [MPa] with a solenoid valve with an $AV = 1.5 \times 10^{-6}$ [m²].

According to the Graph (2), if reading Q_0 when P_1 is 0.8 and P is 0.008 it is 0.7 [kg/h]. Hence, the flow rate $Q = 0.7 \times 1.5 = 1.05$ [kg/h].

(4) Test method

By attaching the equipment for testing with the test circuit shown in Fig. (3) and running water at 5 to 40° C measure the flow rate with a pressure difference of 0.075 MPa. However, the pressure difference needs to be set with a large enough difference so that the Reynolds number does not go below a range of 4×10^{4}

By substituting the measurement results for formula (8) to figure out Av.





Fig. (3) Test circuit based on IEC60534-2-3. JIS B 2005



Flow Characteristics

Note) Use this graph as a guide. In the case of obtaining ar accurate flow rate, refer to pages 25 through to 29.

For Air




How to read the graph

The sonic range pressure to generate a flow rate of 100 d/min (ANR) is $P_1 \cong 0$. MPa for a \emptyset 5 orifice (VX313 \square)

 $P_1 \cong 0.23$ MPa for a Ø2.2 orifice (VX312 \square), and

 $P_1 \cong 0.55$ MPa for a ø* .5 orifice (VX3* \square)

For Water



How to read the graph

When a water flow of 2 //min is generated. $\Gamma \simeq 0.033$ MPs for a ø3 orifice (VX313 \square). $\Gamma \simeq 0.088 \text{ MPa for a } \alpha 2.2 \text{ orifice (VY312}), and$ $\Gamma \simeq 0.31$ MPa for a $\alpha 1.5$ orifice (VY311 \square)



Glossary

Pressure Terminology

1 Maximum operating pressure differential

The maximum pressure differential (the difference between the inlet and outlet pressure) which is allowed for operation, with the valve closed or open. When the downstream pressure is 0 MPa, this becomes the maximum operating pressure.

2 Minimum operating pressure differential

The minimum pressure differential (differential between the inlet pressure and the outlet pressure) required to keep the main valve fully opened.

3 Maximum system pressure

The maximum pressure that can be applied inside the pipelines (line pressure).

(The pressure differential of the solenoid valve unit must be less than the maximum operating pressure differential)

4. Proof pressure

The pressure in which the valve must be withstood without a drop in performance after holding for one minute under prescribed pressure and returning to the operating pressure range. (value under the prescribed conditions)

Electrical Terminology

1 Apparent power (VA)

Volt-ampere is the product of voltage (V) and current (A). Power dissipation (W): For AC $W = V \cdot A \cdot \cos \theta$ For DC, $W = V \cdot A$.

(Note) cos8 shows power factor, cos8 = 0.6

2 Surge voltage

A high voltage which is momentarily generated in the shut-off unit by shutting off the power

3 Enclosure

A degree defined in the "JIS C 0920: Waterproof test of electric machinery/appliance and the degree of protection against the intrusion of solid foreign objects"

IP65: Dust tight, I ow jetproof type

"Low jetproof type" means that no water intrudes inside an equipment that could hinder from operating normally by means of discharging water for 3 minutes in the prescribed manner. Take appropriate protection measures, since a device is not usable in an environment where a water drop is splashed.

Others

1 Material

NBR: Nitrile rubber

FKM: Fluoro rubber Trade name: Viton® D4I-EL™, etc.

EPDM Ethylene propylene rubber

PTFE Polytetrafluoroethylene resin Trade name: Teflon®,

Polyflon® etc FFKM: Perfluoroelastomer

Trade name Kalrez® Chemraz®

2. Oil-free treatment

The degreasing and washing of wetted parts.

3. Passage symbol

In the JIS symbol ($\square\square$ IN and OUT are in a blocked condition () but actually in the case of reverse pressure (OUT>IN), there is a limit to the blocking

(\Diamond) is used to indicate that blocking of reverse pressure is not possible.





Series VX31/32/33

Safety Instructions

The following safety instructions are intended to prevent a hazardous situation and/or equipment damage. These instructions indicate the level of potential hazard by all safety practices, including labels of "Caution", "Warning" or "Danger". To ensure safety, please observe ISO 4414 Note 1), JIS B 8370 Note 2).

↑ Caution: Operator error could result in injury or equipment damage.

Warning: Operator error could result in serious injury or loss of life.

Danger: In extreme conditions, there is a possible result of serious injury or loss of life.

Note 1) ISO 4414: Pneumatic fluid power – General rules relating to systems Note 2) JIS B 8370: General Rules for Pneumatic Equipment

⚠ Warning

1. The compatibility of equipment is the responsibility of the person who designs the system or decides its specifications.

Since the products specified here are used in various operating conditions, their compatibility with a specific system must be based on specifications, post analysis and/or tests to meet a specific requirement. The expected performance and safety assurance will be the responsibility of the person who has determined the compatibility of the system. This person should continuously review the suitability of all items specified, referring to the latest catalog information and taking into consideration the possibility of equipment failure when configuring a system. Be particularly careful in determining the compatibility with the fluid to be used.

2. Only trained personnel should operate machinery and equipment.

The fluid can be dangerous if handled incorrectly. Assembly, handling or maintenance of the system should be performed by trained and experienced operators.

- 3. Do not service machinery/equipment or attempt to remove components until the safety is confirmed.
 - 1. Inspection and maintenance of machinery/equipment should only be performed once measures to prevent falling or runaway of the driven object have been confirmed. Measures to prevent danger from a fluid should also be confirmed.
 - 2. When equipment is to be removed, confirm the safety processes mentioned above, release the fluid pressure and be certain there is no danger from fluid leakage or fluid remaining in the system.
 - 3. Carefully restart the machinery, confirming that safety measures are being implemented.
- If the equipment will be used in the following conditions or environment, please contact SMC first and be sure to take all necessary safety precautions.
 - 1. Conditions and environments beyond the given specifications, or if product is used outdoors.
 - 2. With fluids whose application causes concern due to the type of fluid or additives, etc.
 - 3. An application which has the possibility of having a negative effect on people, property, and therefore requires special safety analysis.





Be sure to read this before handling. For detailed precautions on each series, refer to the main text.

Design

⚠ Warning

1. Cannot be used as an emergency shutoff valve, etc.

The valves presented in this catalog are not designed for safety applications such as an emergency shutoff valve. If the valves are used in this type of system, other reliable safety assurance measures should also be adopted.

2. Extended periods of continuous energization

The solenoid coil will generate heat when continuously energized. Avoid using in a tightly shut container. Install it in a well-ventilated area. Furthermore, do not touch it while it is being energized or right after it is energized.

3. This solenoid valve cannot be used for explosion proof applications.

4. Maintenance space

The installation should allow sufficient space for maintenance activities.

5. Liquid rings

In cases with a flowing liquid, provide a bypass valve in the system to prevent the liquid from entering the liquid seal circuit.

6. Actuator drive

When an actuator, such as a cylinder, is to be driven using a valve, take appropriate measures to prevent potential danger caused by actuator operation.

7. Pressure (including vacuum) holding

It is not usable for an application such as holding the pressure (including vacuum) inside of a pressure vessel because air leakage is entailed in a valve.

- 8. When the conduit type is used as equivalent to an IP65 enclosure, install a wiring conduit, etc.
- 9. When an impact, such as water hammer, etc., caused by the rapid pressure fluctuation is applied, the solenoid valve may be damaged. Give an attention to it.

Selection

Marning

1. Confirm the specifications.

Give careful consideration to the operating conditions such as the application, fluid and environment, and use within the operating ranges specified in this catalog.

2. Fluid

1) Type of fluid

Before using a fluid, confirm whether it is compatible with the materials from each model by referring to the fluids listed in this catalog. Use a fluid with a dynamic viscosity of 50 mm²/s or less. If there is something you do not know, please contact us.

2) Inflammable oil, Gas,

Confirm the specification for leakage in the interior and/or exterior area.

Selection

Marning

3) Corrosive gas

Cannot be used since it will lead to cracks by stress corrosion or result in other incidents.

- 4) Use an oil-free specification when any oily particle must not enter the passage.
- Applicable fluid on the list may not be used depending on the operating condition.

Give adequate confirmation, and then determine a model, just because the compatibility list shows the general case.

3. Fluid quality

The use of a fluid which contains foreign matter can cause problems such as malfunction and seal failure by promoting wear of the valve seat and armature, and by sticking to the sliding parts of the armature, etc. Install a suitable filter (strainer) immediately upstream from the valve. As a general rule, use 80 to 100 mesh.

When used to supply water to boilers, substances such as calcium and magnesium which generate hard scale and sludge are included. Since this scale and sludge can cause the valve to malfunction, install water softening equipment, and a filter (strainer) directly upstream from the valve to remove these substances.

4. Air quality

1) Use clean air.

Do not use compressed air which includes chemicals, synthetic oils containing organic solvents, salt or corrosive gases, etc., as it can cause damage or malfunction.

2) Install air filters.

Install air filters close to valves at their upstream side. A filtration degree of 5 m or less should be selected.

3) Install an air dryer or after-cooler, etc.

Compressed air that includes excessive drainage may cause malfunction of valves and other pneumatic equipment. To prevent this, install an air dryer or after-cooler, etc.

If excessive carbon powder is generated, eliminate it by installing mist separators at the upstream side of valves.

If excessive carbon powder is generated by the compressor, it may adhere to the inside of the valves and cause a malfunction

Refer to SMC's "Best Pneumatics 2004" Vol. 14 catalog for further details on compressed air quality.

5. Ambient environment

Use within the operable ambient temperature range. Confirm the compatibility between the product's composition materials and the ambient atmosphere. Be sure that the fluid used does not touch the external surface of the product.

6. Countermeasures against static electricity

Take measures to prevent static electricity since some fluids can cause static electricity.

7. For the low particle generation specification, confirm us separately.






Be sure to read this before handling. For detailed precautions on each series, refer to the main text.

Selection

1. Leakage voltage

Particularly when using a resistor in parallel with a switching element and using a C-R element (surge voltage suppressor) to protect the switching element, take note that leakage current will flow through the resistor, C-R element, etc., creating a possible danger that the valve may not turn off.



AC/Class B coil: 5% or less of rated voltage AC/Class H coil: 20% or less of rated voltage DC coil : 2% or less of rated voltage

2. Low temperature operation

- The valve can be used in an ambient temperature of between -10 to -20°C, however take measures to prevent freezing or solidification of impurities, etc.
- When using valves for water application in cold climates, take appropriate countermeasures to prevent the water from freezing in tubing after cutting the water supply from the pump, by draining the water, etc.

When heating by steam, be careful not to expose the coil portion to steam. Installation of dryer, heat retaining of the body is recommended to prevent a freezing condition in which the dew point temperature is high and the ambient temperature is low, and the high flow runs.

Mounting

Marning

1. If air leakage increases or equipment does not operate properly, stop operation.

After mounting is completed, confirm that it has been done correctly by performing a suitable function test.

2. Do not apply external force to the coil section.

When tightening is performed, apply a wrench or other tool to the outside of the piping connection parts.

3. Be sure not to position the coil downwards.

When mounting a valve with its coil positioned downwards, foreign objects in the fluid will adhere to the iron core leading to a malfunction.

4. Do not warm the coil assembly with a heat insulator, etc.

Use tape, heaters, etc., for freeze prevention on the piping and body only. They can cause the coil to burn out.

- 5. Secure with brackets, except in the case of steel piping and copper fittings.
- 6. Avoid sources of vibration, or adjust the arm from the body to the minimum length so that resonance will not occur.
- 7. Painting and coating

Warnings or specifications printed or labeled on the product should not be erased, removed or covered up. **Piping**

⚠ Caution

1. Preparation before piping


Before piping is connected, it should be thoroughly blown out with air (flushing) or washed to remove chips, cutting oil and other debris from inside the pipe.

Install piping so that it does not apply pulling, pressing, bending or other forces on the valve body.

2. Wrapping of pipe tape

When connecting pipes, fittings, etc., be sure that chips from the pipe threads and sealing material do not enter the valve.

Furthermore, when pipe tape is used, leave 1.5 to 2 thread ridges exposed at the end of the threads.



- 3. Avoid connecting ground lines to piping, as this may cause electric corrosion of the system.
- 4. Always tighten threads with the proper tightening torque.

When attaching fittings to valves, tighten with the proper tightening torque shown below.

Tightening Torque for Piping

Connection threads	Proper tightening torque N⋅m
Rc 1/8	7 to 9
Rc 1/4	12 to 14
Rc 3/8	22 to 24
Rc 1/2	28 to 30

5. Connection of piping to products

When connecting piping to a product, refer to its instruction manual to avoid mistakes regarding the supply port, etc.

6. Steam generated in a boiler contains a large amount of drainage.

Be sure to operate it with a drain trap installed.

7. In applications such as vacuum and non-leak specifications, use caution specifically against the contamination of foreign matter or airtightness of the fittings.



Be sure to read this before handling. For detailed precautions on each series, refer to the main text.

Wiring

- 1 As a rule, use electrical wire with a cross sectional area of 0.5 to 1.25 mm² for wiring Furthermore, do not allow excessive force to be applied to the lines.
- 2. Use electrical circuits which do not generate chattering in their contacts.
- 3. Use voltage which is within 10% of the rated voltage.

In cases with a DC power supply where importance is placed on responsiveness, stay within 5% of the rated value. The voltage drop is the value in the lead wire section connecting the coil.


4. When a surge from the solenoid affects the electrical circuitry, install a surge absorber etc., in parallel with the solenoid.

Or adopt an option that comes with the surge voltage protection circuit. (However, a surge voltage occurs even if the surge voltage protection circuit is For details, please consult with us.)

Electrical Connections

Grommet

Class H coil: AWG18 Insulator O.D. 2.2 rnm
Class B coil: AWG20 Insulator O.D. 2.5 mm




Dotad valtage	Lead wire color							
Rated voltage	1)	2						
DC (Class B only)	Black	Red						
100 VAC	Blue	Blue						
200 VAC	Red	Red						
Other AC	Gray	Gray						

^{*} There is no polarity


DIN terminal (Class B only)

Since internal connections are as shown below for the DIN terminal make connections to the power supply accordingly



Terminal no.	1	2
DIN terminal	+ (-)	- (+)

- * There is no polarity
- Use compatible heavy duty cords with cable C.D. of ø6 to 12.
- Use the tightening torques below for each section



Note) For an outside cable diameter of 69 to 12 mm, remove the internal parts of the rubber seal before using






Be sure to read this before handling. For detailed precautions on each series, refer to the main text.

Electrical Connections

Conduit terminal

In the case of the conduit terminal, make connections according to the marks shown below

- Use the tightening torques below for each section.
- Properly seal the terminal connection (G1/2) with the special wiring conduit, etc.




View A-A

(Internal connection diagram)

Conduit

When used as an IP65 equivalent, use seal (part no. VCW20-15-6) to install the wiring conduit. Also, use the tightening torque below for the conduit.

Class H coil AWG18 Insulator O.D. 2.2 mm Class B coil: AWG20 Insulator O.D. 2.4 mm



(Bore size G1/2 Tightening torque 0.5 to 0.6 N m)

Dated voltage	Lead wire color							
Rated voltage	1	2						
DC	Black	Red						
100 VAC	Blue	Blue						
200 VAC	Red	Red						
Other AC	Gray	Gray						

* There is no polarity for DC

Description	Part no.
Seal	VCW20-15-6


Note) Please order separately.

Electrical Circuits


⚠ Caution

DC circuit


Grommet, Conduit Conduit terminal, DIN terminal



Conduit terminal DIN terminal




Grommet, Conduit terminal, DIN terminal



With surge voltage suppressor


Conduit terminal DIN terminal



With light/surge voltage suppressor

AC/Class B coil circuit


Grommet, Conduit Conduit terminal, DIN terminal



Without electrical option


* Surge voltage suppressor is attached to the AC/Class Bicoil, as a standard

Conduit terminal, DIN terminal




AC/Class H coil circuit

Grommet, Conduit Conduit terminal




Without electrical option

Grommet, Conduit terminal




With surge voltage suppressor

Conduit terminal



Conduit termina



With light/surge voltage supressor





Be sure to read this before handling. For detailed precautions on each series, refer to the main text.

Operating Environment

Marning

- 1. Do not use the valves in an atmosphere having corrosive gases, chemicals, salt water, water, steam, or where there is direct contact with any of these.
- 2. Do not use in explosive atmospheres.
- 3. Do not use in locations subject to vibration or impact.
- 4. Do not use in locations where radiated heat will be received from nearby heat sources.
- 5. Employ suitable protective measures in locations where there is contact with water droplets, oil or welding spatter, etc.

Lubrication

1. This solenoid valve can be operated without lubrication.

If a lubricant is used in the system, use turbine oil Class 1, ISO VG32 (with no additive). But do not lubricate a valve with EPDM seal.

Refer to the table of brand name of lubricants compliant with Class 1 turbine oil (with no additive), ISO VG32.

Class 1 Turbine Oil (with no additive), ISO VG32

Classification of viscosity (cst) according to (40C) ISO Grade	32
Idemitsu Kosan Co.,Ltd.	Turbine oil P-32
Nippon Oil Corp.	Turbine oil 32
Cosmo Oil Co.,Ltd.	Cosmo turbine 32
Japan Energy Corp.	Kyodo turbine 32
Kygnus Oil Co.	Turbine oil 32
Kyushu Oil Co.	Stork turbine 32
Nippon Oil Corp.	Mitsubishi turbine 32
Showa Shell Sekiyu K.K.	Turbine 32
Tonen General Sekiyu K.K.	General R turbine 32
Fuji Kosan Co.,Ltd.	Fucoal turbine 32
Discourse of CMO as a solid as Observed in a sill (with a delitional) 100 MOOO	

Please contact SMC regarding Class 2 turbine oil (with additives), ISO VG32.

Maintenance

Marning

1 Removing the product

The valve will reach a high temperature when used with high temperature fluids. Confirm that the valve temperature has dropped sufficiently before performing work. If touched inadvertently, there is a danger of being burned.

- 1. Shut off the fluid supply and release the fluid pressure in the system.
- 2. Shut off the power supply.
- 3. Demount the product.

2. Low frequency operation

Switch valves at least once every 30 days to prevent malfunction. Also, in order to use it under the optimum state, conduct a regular inspection once a half year.

Maintenance

⚠ Caution

1. Filters and strainers

- 1. Be careful regarding clogging of filters and strainers.
- 2. Replace filter elements after one year of use, or earlier if the pressure drop reaches 0.1 MPa.
- Clean strainers when the pressure drop reaches 0.1 MPa.

2. Lubrication

When using after lubricating, never forget to lubricate continuously.

3. Storage

In case of long term storage after use with heated water, thoroughly remove all moisture to prevent rust and deterioration of rubber materials, etc.

4. Exhaust the drain from an air filter periodically.

Operating Precautions

Marning

 Valves will reach high temperatures from high temperature fluids. Use caution, as there is a danger of being burned if a valve is touched directly.





SMC Corporation

Akihabara UDX 15F, 4-14-1, Sotokanda, Chiyoda-ku, Tokyo 101-0021, JAPAN Phone: 03-5207-8249 FAX: 03-5298-5362 URL http://www.smcworld.com © 2007 SMC Corporation All Rights Reserved

Specifications are subject to change without prior notice and any obligation on the part of the manufacturer