SY

SYJ

٧K

٧Z

VΤ

۷P

۷G

VP

S070

۷Q

 VKF

VQZ

٧Z

VS

VFN

3 Port Solenoid Valve **Metal Seal**

Series VZ200

Large flow capacity

Low power consumption: 1.8 W (75 mA, 24 VDC)

Plug connector

One-touch wiring of plug connectors

Common pilot exhaust subplate mounted and manifold




Body ported



Base mounted

JIS Symbol



⚠ Caution

For Safety Instructions and Solenoid Valve Precautions, refer to pages 4-18-2 to 4-18-6.

Model

Piping	Type of	Choice of pilot valve exhaust		
	actuation	Individual exhaust	Common exhaust	
Body ported	N.C.	VZ212	VZ212 *	
	N.O.	VZ222	VZ222 *	
Base mounted	N.C.	_	VZ215	
	N.O.	_	VZ225	

* Body ported type provides both individual exhaust and common exhaust.

Specifications

Fluid	Air/Inert gas
Maximum operating pressure	1.0 MPa
Minimum operating pressure	0.1 MPa
Proof pressure	1.5 MPa
Ambient and fluid temperature	−10 to 50°C
Lubrication	Not required
Enclosure	Dusproof (5)
Manual override	Push type (Safety style), Locking type (Tool required), Locking type (Manual)
Shock/Vibration resistance (m/s²)	150/50 ⁽⁶⁾

Туре		Body ported		Base mounted (With sub-plate)			
Specifications		N.C. valve	N.O. valve	N.C. valve	N.O. valve		
Por	t size		M	5	Rc	Rc 1/8	
ics	1 0	C[dm3/(s·bar)]	0.60	0.60	1.0	0.90	
Flow characteristics	$1 \rightarrow 2$	b	0.43	0.43	0.30	0.25	
acte (P →	$(P \rightarrow A)$	Cv	0.15	0.15	0.25	0.21	
hara	2 → 3	C[dm3/(s.bar)]	0.52	0.52	0.85	0.85	
≥ ≥	$(A \rightarrow R)$	b	0.35	0.35	0.35	0.35	
은 (A → h	(A → n)	Cv	0.13	0.13	0.22	0.22	
Max. operating frequency (c/s) (AC/DC) (1)		20		20			
Response time (ms) (AC/DC) (2)		17/17 or less		17/17 or less			
Weight (kg) (3)		0.085		0.155			

Note 1) Minimum operating frequency: as per JIS B 8373 (Once in 30 days)
Note 2) Based on JIS B 8375-1981 (Supply pressure; 0.5 MPa; without surge voltage suppressor)
Note 3) Value for grommet (Sub-plate weight: 0.03 kg)
Note 4) "Note 1)" and "Note 2)" are with controlled clean air.
Note 5) Based on JIS C 0920
Note 6) Impact resistance: No malfunction occurred when it is tested with a drop tester in the axial direction and at the right angles to the main valve and armature in both energized and de-energized states every once for each condition.

(Values at the initial period)
Vibration resistance: No malfunction occurred in a one-sweep test between 45 and 2000 Hz. Test was performed at both energized and de-energized states in the axial direction and at the right angles to the main valve and armature. (Values at the initial period)

lenoid Specifications

Solenola Specific	* Option				
Electrical entry			Grommet (G), Plug connector (L), Plug connector (M), DIN terminal (D)		
Coil rated voltage (V)	AC 50/60 Hz		100, 200, 24 *, 48 *, 110 *, 220 *		
Con rated voltage (v)		DC	24, 6 *, 12 *, 48 *		
Allowable voltage fluctuation (%)		%)	-15 to +10% of rated voltage		
Coil insulation type			Class E or equivalent (120°C) (2)		
Temperature rise (°C)			45 or less		
Power consumption (W)		DC	1.8 (With indicator light: 2.1)		
Apparent namer (VA)	AC	Inrush	4.5/50 Hz, 4.2/60 Hz		
Apparent power (VA)		Holding	3.5/50 Hz, 3/60 Hz		
Surge voltage suppressor (1)			DC: Diode, AC: ZNR		
Indicator light			DC: LED (Red), AC: Neon bulb		


Note 1) In the case of grommet type, it is equipped on the middle of lead wire. Note 2) Based on JIS C 4003

Option

Description		Part no.	Note
Foot bracket (With screw) (1)		VZ2000-37A-2	For VZ2□2
Silencer	M5	AN120-M5	Noise reduction: 18 dB or more (ø8 x 17ℓ)
	R 1/8 (2)	AN110-01	Noise reduction: 21 dB or more (Ø13 x 38ℓ)

Note 1) For body ported type Note 2) For sub-plate mounted type








3 Port Solenoid Valve Metal Seal, Body Ported/Base Mounted Series VZ200

Construction (Body ported)



Component Par	rts
---------------	-----

No.	Description	Material	Note
1	Body	Aluminum die-casted	Platinum silver
2	Spool/Sleeve	Stainless steel	
3	Piston	Polyacetal	

Replacement	Parts
-------------	--------------

<u> </u>			
No.	Description	Material	Part no.
4	Return spring	Stainless steel	
(5)	O-ring	NBR	
6	Seal	NBR	
7	O-ring	NBR	
8	O-ring	NBR	
9	Mini Y seal	NBR	
10	Round head combination screw	Carbon steel	
11)	Round head combination screw	Carbon steel	
12	Pilot valve assembly		SCZ2□□□-□-□
11)	Round head combination screw		SCZ2□□□-□-□

V100

SY

SYJ VK

V 1 V

VZ

VT

VP

VG

VP S070

VQ

VKF


VQZ

٧Z

٧S

VFN

Construction (Sub-plate mounted)




No.	Description	Material	Note
1	Body	Aluminum die-casted	Platinum silver
2	Spool/Sleeve	Stainless steel	
3	Piston	Polyacetal	
4	Sub-plate	Aluminum die-casted	Platinum silver

Sub-plate Assembly Part No.: VZ200-S-01

* Mounting bolt and gasket are not attached.

- 1 - 1			
No.	Description	Material	Note
(5)	Return spring	Stainless steel	
6	Gasket	NBR	
7	O-ring	NBR	
8	Seal	NBR	
9	O-ring	NBR	
10	O-ring	NBR	
11	Mini Y seal	NBR	
12	Round head combination screw	Carbon steel	
13	Round head combination screw	Carbon steel	
14)	Round head combination screw	Carbon steel	
15	Pilot valve assembly	_	SCZ2□□□-□-□

How to Order Pilot Valve Assembly



SY

SYJ

۷K

٧Z

۷G

۷P

S070

VQ

VKF

VQZ


٧Z

VS


VFN

3 Port Solenoid Valve Metal Seal, Body Ported/Base Mounted Series VZ200

Dimensions: Body Ported




Dimensions: Sub-plate Mounted



Manifold Specifications

Manifold Variations: VV3Z2



Model


Manifold type			Single base, B mount				
Passage			Common SUP/EXH type				
	Valve s	stations		M	ax. 20 stations		
Manifold	base model	VV3Z2-20	VV3Z2-30	VV3	Z 2-50	VV3Z2-S50	
		Individual exhaust	Common exhau	st Commor	n exhaust	Common exhaust	
			,	1.	Built-in One-touch fittings	Built-in One-touch fittings	
Pilot valve exhaust							
2(A) port	Piping direction/ Location	Top/Valve		Side/Base (Opposi	Side/Base (Opposite side of solenoid)		
· / ·	Port size	M5 x 0.8		M5 x 0.8, Rc 1/8	C4, C6	C4, C6	
P, E port	Port size	Rc	1/8	Rc 1/8			
Applicable valve model		VZ212-□□□-M5		VZ215-□□□			
		VZ222-	□□-M5		VZ225-□□□		
vaive iiic	Juei	Body ported		Base m	Base mounted (Without sub-plate)		
Blanking	plate	VVZ200-32A-1	VVZ200-31A-1	VVZ200-31A-2	VZ200-31A-2 VVZ200-32A-2		

Screws and Gasket Assembly Part No.

Model	Part no.
VV3Z2-20	BG-VZ202
VV3Z2-30	BG-VZ203
VV3Z2-50 -S50	BG-VZ205

How to Order Manifold Base

VV3Z2-50-061-C6



Symbol	Piping	P, E port Port size	model model
20	Body ported (Individual pilot exhaust)	Rc 1/8	VZ2□2
30	Body ported (Common pilot exhaust)	Rc 1/8	VZ2□2
50	Base mounted (Common pilot exhaust) A port direction: Opposite side of solenoid valve	Rc 1/8	VZ2□5
			I

* Type S50 is available only with built-in One-touch fittings.

Base mounted

(Common pilot exhaust)

A port direction: Same side of solenoid valve

S50³

Instruct by specifying the valves, blanking plate option to be mounted on the manifold along with the manifold base model no. And for the order of valves installation or option's position, instruct separately by the manifold specification sheet.

* VV3Z2-S50: Only C4 and C6

(Example)

 <Top ported, individual pilot exhaust>
 <Side ported, common pilot exhaust>

 VV3Z2-20-081 (8 stations)
 VV3Z2-50081-C6 (8 stations)

 VZ212-1G-M5----- 5 pcs.
 VZ215-5M------5 pcs.

 VZ212-1G-M5----- 2 pcs.
 VZ215-5M------3 pcs.

 VZ215-5M------ 3 pcs.
 VZ215-5M------3 pcs.

VVZ200-32A-1····· 1 pc. (Blanking plate)

<Side ported, common pilot exhaust> VV3Z2-50-081-01 (8 stations) VZ215-1G....... 5 pcs.

VZ225-1G··········· 2 pcs. VVZ200-32A-2····· 1 pc. (Blanking plate)

SMC

VZ2□5

SY

V100

VK

٧Z

VT

VP

VG

VP

S070

VQ VKF


VQZ


VZ

VS

VFN

Dimensions: Individual Exhaust/Common Exhaust





SY

SYJ

۷K

٧Z

۷G

۷P

S070

VQ

VKF

VQZ


٧Z

VS

VFN

3 Port Solenoid Valve Metal Seal, Body Ported/Base Mounted Series VZ200

Dimensions: Common Exhaust



4-15-9

3 Port Solenoid Valve **Metal Seal**

Series VZ400

Large flow capacity

Low power consumption: 1.8 W (75 mA, 24 VDC)

Plug connector

One-touch wiring of plug connectors

Common pilot exhaust subplate mounted and manifold





Base mounted

JIS Symbol





Model

Dining	Type of	Choice of pilot valve exhaust		
Piping	actuation	Individual exhaust	Common exhaust	
Pady parted	N.C.	VZ412	VZ412*	
Body ported	N.O.	VZ422	VZ422*	
Door mounted	N.C.	_	VZ415	
Base mounted	N.O.	_	VZ425	

* Body ported type provides both individual exhaust and common exhaust.

Specifications

Fluid	Air/Inert gas
Maximum operating pressure	1.0 MPa
Minimum operating pressure	0.15 MPa
Proof pressure	1.5 MPa
Ambient and fluid temperature	−10 to 50°C
Lubrication	Not required
Enclosure	Dustproof (5)
Manual override	Push type (Safety style), Locking type (Tool required), Locking type (Manual)
Shock/Vibration resistance (m/s²)	150/50 ⁽⁶⁾

Туре			Body _I	oorted	Base mounted (With sub-plate)		
Specifications			N.C. valve	N.O. valve	N.C. valve	N.O. valve	
Port	size		Rc	1/8	Rc 1/8, 1/4		
SS	1 0	C[dm ³ /(s·bar)]	2.0	2.0	2.4	2.4	
ərist	$ \begin{array}{c} 1 \to 2 \\ (P \to A) \end{array} $	b	0.14	0.17	0.19	0.19	
acte		Cv	0.49	0.49	0.57	0.57	
Flow characteristics	$2 \rightarrow 3$ (A \rightarrow R)	C[dm ² /(s·bar)]	2.2	2.2	2.2	1.9	
§		b	0.17	0.17	0.11	0.32	
윤		Cv	0.53	0.53	0.49	0.45	
Max. operating frequency (c/s) (AC/DC) (1)			15		15		
Response time (ms) (AC/DC) (2)			21/21 or less		21/21 or less		
Weig	ht (kg) (3)		0.125		0.250		

Note 1) Minimum operating frequency: As per JIS B 8373 (Once in 30 days)

Note 2) Based on JIS B 8375-1981 (Supply pressure; 0.5 MPa; without surge voltage suppressor)

Note 3) Value for grommet (Sub-plate weight: 0.055 kg)

Note 4) "Note 1)" and "Note 2)" are with controlled clean air.

Note 5) Based on JIS C 0920

Note 6) Impact resistance: No malfunction occurred when it is tested with a drop tester in the axial direction and at the right angles to the main valve and armature in both energized and de-energized states every once for each condition. (Values

at the initial period)

Vibration resistance: No malfunction occurred in a one-sweep test between 45 and 2000 Hz. Test was performed at both energized and de-energized states in the axial direction and at the right angles to the main valve and armature.

Solenoid Specifications

* Option

<u> </u>						
Electrical entry			Grommet (G), Plug connector (L), Plug connector (M), DIN terminal (D)			
Cail retail valtage (1/)	AC 50)/60 Hz	100, 200, 24*, 48*, 110*, 220*			
Coil rated voltage (V)	DC		24, 6*, 12*, 48*			
Allowable voltage fluctuat	ion (%)		-15 to +10% of rated voltage			
Coil insulation type			Class E or equivalent (120°C) (2)			
Temperature rise (°C)			45 or less			
Power consumption (W)	D	С	1.8 (With indicator light: 2.1)			
Apparent newer (VA)	40	Inrush	4.5/50 Hz, 4.2/60 Hz			
Apparent power (VA)	AC Holding		3.5/50 Hz, 3/60 Hz			
Surge voltage suppressor	(1)		DC: Diode, AC: ZNR			
Indicator light			DC: LED (Red), AC: Neon bulb			

(Values at the initial period)



Note 1) In the case of grommet type, it is equipped on the middle of lead wire.

Note 2) Based on JIS C 4003

Option

Description		Part no.	Note
Foot bracket (With screw) (1)		VZ4000-22A	For VZ4□2
Silencer	R 1/8	AN110-01	Noise reduction: 21 dB (Ø13 x 38ℓ)
Silencer	R 1/4 (2)	AN203-02	Noise reduction: 25 dB (Ø16 x 36ℓ)




Note 1) For body ported type Note 2) For sub-base mounted type



3 Port Solenoid Valve Metal Seal, Body Ported/Base Mounted Series VZ400





V100 SY

SYJ

٧K

٧Z

۷G ۷P

S070

VQ

VKFVQZ

٧Z

VS

4-15-11


SCZ4□□□-□-□

Round head combination screw


13 Pilot valve assembly

Carbon steel

Construction: Sub-plate Mounted



How to Order Pilot Valve Assembly



Round head combination screw

Round head combination screw

(i) Pilot valve assembly

Carbon steel

Carbon steel

SCZ4□□□-□-□

SY

SYJ

۷K

٧Z

۷G

۷P

S070

VQ

VKF

VQZ


٧Z

VS


VFN

3 Port Solenoid Valve Metal Seal, Body Ported/Base Mounted Series VZ400

Dimensions: Body Ported



Dimensions: Sub-plate Mounted



Manifold Specifications

Manifold Variations: VV3Z4

VV3Z4-50-061-□ VV3Z4-20-061 VV3Z4-20-061

VV3Z4-50-061-C8


Model

	Manifo	ld type		Single base, B mount			
	Passa	ge		Common SUP/EXH type			
	Valve	stations		M	ax. 20 stations		
Manifold	base model	VV3Z4-20	VV3Z4-30	VV3Z	Z4-50	VV3Z4-S50	
		Individual exhaust	Common exhau	st Commor	n exhaust	Common exhaust	
			1.	1.	Built-in One-touch fittings	Built-in One-touch fittings	
Pilot valve exhaust							
2(A)	Piping direction/ Location	Top/Valve		Side/Base (Opposi	Side/Base (Opposite side of solenoid)		
port	Port size	Rc 1/8		Rc1/8, 1/4	C6, C8	C6, C8	
P, E port	Port size	Rc 1/4		Rc 1/4			
Applicable		VZ412□□□-01		VZ415-□□□			
valve mo		VZ422	□□-01		VZ425-□□□		
vaive model		Body	ported	Base me	Base mounted (Without sub-plate)		
Blanking plate		VVZ400-31A-1	VVZ400-32A-	1 VVZ400-32A-2	VVZ400-32A-2 VVZ400-31A-2		

Screws and Gasket Assembly Part No.

Model	Part no.
VV3Z4-20	BG-VZ402
VV3Z4-30	BG-VZ403
VV3Z4-50 -S50	BG-VZ405

How to Order Manifold Base



Symbol	Piping	P, E port Port size	Applicable valve model
20	Body ported (Individual pilot exhaust)	Rc 1/4	VZ4□2
30	Body ported (Common pilot exhaust)	Rc 1/4	VZ4□2
50	Base mounted (Common pilot exhaust) 2(A) port direction: opposite side of solenoid valve	Rc 1/4	VZ4□5
S50*	Base mounted (Common pilot exhaust) 2(A) port direction: same side of solenoid valve	Rc 1/4	VZ4□5

 $_{\lambda}$ st Type S50 is available only with built-in One-touch fittings.

Instruct by specifying the valves, blanking plate option to be mounted on the manifold along with the manifold base model no. And for the order of valves installation or option's position, instruct separately by the manifold specification sheet.

(Example)

<Top ported, common pilot exhaust> VV3Z4-30-061 (6 stations) VZ412-1G-01----- 3 pcs. VZ412-1G-01----- 2 pcs

VZ412-1G-01······ 2 pcs. VVZ400-32A-1····· 1 pc. (Blanking plate)

<Side ported, common pilot exhaust> VV3Z4-50-061-01 (6 stations) VZ415-1G.......3 pcs. VZ425-1G......2 pcs.

VVZ400-32A-2·····1 pc. (Blanking plate)

V100

SY

SYJ

\/**7**

VZ

...

VG

VP

S070

VQ

VKF

VQZ

VZ

VS

VFN


<Side ported, common pilot exhaust>


VV3Z4-S50-061-C8 (6 stations)

VZ415-5L.....3 pcs.

VZ415-5L.....3 pcs.

Dimensions: Individual Exhaust/Common Exhaust





SY

SYJ

۷K

٧Z

VP

۷G

۷P

S070

VQ

VKF

VQZ


٧Z

VS

VFN

3 Port Solenoid Valve Metal Seal, Body Ported/Base Mounted Series VZ400





4-15-17

Series VZ200/400


⚠ Precaution 1

Be sure to read before handling. For Safety Instructions and Solenoid Valve Precautions, refer to page 4-18-2.


Surge Voltage Suppressor

⚠ Caution

Grommet Type



Plug Connector Type




In applications where the supply voltage is DC, correctly connect the lead wires to + (positive) and – (negative) indications on the connector or to the markings.

For those on which the lead wires have been pre-wired, the positive side is red and negative side is black.

How to Use Plug Connector


Attaching and detaching connectors

- To attach a connector, hold the lever and connector unit between your fingers and insert straight onto the pins of the solenoid valve so that the lever's pawl is pushed into the groove and locks.
- To detach a connector, remove the pawl from the groove by pushing the lever downward with your thumb, and pull the connector straight out.



Crimping the Lead Wire and Socket

Peel 3.2 to 3.7 mm of the tip of lead wire, enter the core wires neatly into a socket and crimp it with a special crimp tool. Be careful so that the cover of lead wire does not enter into the crimping part. (Crimping tool part no.: DXT 170-75-1)



Connector assembly part no.

Lead wire color Lead wire length

Symbol Lead wire length (mm)

300 600

1000

1500

2000

2500

3000

Nil

6

10

15

25


30

Symbol	With socket Lead wire	Note
Nil	Socket only (2 pcs.)	Without lead wire
1 Blue (2)		For 100 VAC
2	Red (2)	For 200 VAC
3	Gray (2)	Another VAC
4	Red: +, Black: -	For DC

Note) When ordering a valve with a lead wire of 600 mm or longer, be sure to indicate the model number of the valve without connector and connector assembly.

Ex.)
For lead wire length (1000 mm)
Solenoid valve:
VZ2150-5M0-01..........5 pcs.
Connector assembly:
DXT170-80-4A-10.......5 pcs.

DIN Terminal Type



In the case of DC wiring, connect terminal no. 1 of the connector to the positive [+] side, and terminal no. 2 to the negative [-] side. (Refer to the marks on the terminal board.)

Series **VZ200/400**

⚠ Precaution 2

Be sure to read before handling. For Safety Instructions and Solenoid Valve Precautions, refer to page 4-18-2.

How to Use Plug Connector

⚠ Caution


Attaching and detaching lead wires with sockets

1. Attaching

Insert the sockets into the square holes of the connector (with + and - indication) and continue to push the sockets all the way in until the lock by hooking into the seats in the connector. (When they are pushed in, their hooks open and they are locked automatically.) Then confirm that they are locked by pulling lightly on the lead wires.

2. Detaching

To detach a socket from a connector, pull out the lead wire while pressing the socket's hook with a stick having a thin tip (approx. 1 mm). If the socket will be used again, first spread the hook outward.



How to Calculate the Flow Rate


For obtaining the flow rate, refer to page 4-1-6.

Connector assembly with protective cover


Connector assembly with protective cover enhances dust protection.

- Effective to prevent short circuit accidents due to penetration of foreign matter into the connector section.
- The material of cover is chloroprene rubber for electricity which is excellent in weathering and electrical insulating properties. But don't splash with cutting oil.
- Simple and unencumbered appearance by adopting round-shaped cord.

How to Order



Dimensions: Connector Assembly with Cover



20

25

30

2000

2500

3000

V100

SY

SYJ

VK

٧Z

VI

VG

۷P

S070 VQ

VKF

VQZ

٧Z

VS

VFN

Series VZ200/400

Precaution 3

Be sure to read before handling. For Safety Instructions and Solenoid Valve Precautions, refer to page 4-18-2.

How to Wire DIN Terminal

⚠ Caution

Connection

- 1. Loosen the set screw and pull out the connector from the terminal block of the solenoid.
- Pull out screw and insert a screwdriver to the slit area near the bottom of terminal block to separate block and housing.
- Loosen the terminal screws (slotted screws) on the terminal block, insert the core of the lead wire into the terminal in accordance with the prescribed connection method, and attach securely with the terminal screws.
- 4. Tighten the ground nut to secure the wire.

Change of electrical entry (Orientation)

After separating terminal block and housing, the cord entry direction can be changed by attaching the housing in the desired direction (4 directions in 90 increments).

* In the case of w/indicator light, avoid damaging the indicator light with lead wire.


Precautions

Plug a connector in or out vertically, never at an angle.

Applicable cable

O.D.: ø3.5 to ø7

(Reference) 0.5 mm² 2 core and 3 core wires equivalent to JIS C 3306.



DIN Terminal Part No.

Without indicato	r light		DXT170-176-1			
With Indicator Light						
Rated voltage	Voltage symbol		Part no.			
100 VAC	100	V	DXT170-176-2-01			
200 VAC	200V		DXT170-176-2-02			
110 VAC	110V		DXT170-176-2-03			
220 VAC	220V		DXT170-176-2-04			
240 VAC	240	V	DXT170-176-2-07			
6 VDC	6V	'D	DXT170-176-3-51			
12 VDC	12VD		DXT170-176-3-06			
24 VDC	24VD		DXT170-176-3-05			
48 VDC	48V	'D	DXT170-176-3-53			

Circuit with Indicator Light

